

VFS Trace Overview

View | Lots

- VFS Trace tracks key maintenance and logistics data, installed CAD/PADs, and life support equipment.
- Data is used for maintenance scheduling, CAD/PAD Web ordering, procurement planning, and for the location and removal of potentially defective components.
- VFS Trace contains two modules: CAD/PAD and Life Support.
- Each module supports three levels of maintenance: organizational level (O level), intermediate level (I level), and depot level.
- User ID determines which level of maintenance to which the user has access.



Audio:

The VFS Trace application was created to aid in tracking key maintenance and logistics data, installed CADs and PADs, and life support equipment. The data contained within the system will be used for maintenance scheduling, CAD PAD ordering, procurement planning, and for the location and removal of potentially defective components. The Trace CAD PAD and Life Support modules support organizational, intermediate, and depot-level maintenance.

Trace CAD/PAD Intro

View | Lots

- The Trace CAD/PAD system tracks installed assets.
- This system tracks data used to support daily maintenance planning decisions, serial numbers, and expiration/extension dates.
- Trace CAD/PAD enables users to track aircraft to the assigned squadron or maintenance unit, controls the users that can maintain the data, and provides standardized output reports that aid maintenance activities.
- Trace CAD/PAD contains links to other VFS modules, enabling automated updates of technical and service life data as the CAD/PAD program data changes.
- Automated email features keep users informed of changes affecting their equipment.
- The Trace CAD/PAD system shall be updated as CAD/PAD change-outs occur.




Audio:

The purpose of the Trace CAD/PAD system is to track installed assets. This system provides the capability of tracking aircraft, controlling user access rights, and providing standardized output reports. Trace CAD/PAD contains links to other VFS modules to provide automated updates of technical and service life data. It also contains an automated email feature to inform users of changes affecting their equipment. This subsystem is updated as CAD/PAD change-outs occur.

Trace CAD/PAD Module

View | Lots

- Click the Trace CAD/PAD button from the VFS Application Module Menu.




Audio:

Click the Trace CAD/PAD button from the VFS Application Module Menu to access the Trace CAD/PAD module.

Expired Assets Notice

View | Lots



- If expired assets are found in the system, a message will display.

NOTE: This message will display each time you log on to the Trace CAD/PAD module until all expired assets are removed.



Audio:


When expired assets are in the system for your squadron, a notice will display. This message will display each time you enter the Trace CAD/PAD module until all expired assets are removed from the system.

Expired Assets Report

View | Lots

- An expired asset report will display when expired assets are found in the system.
- Click the printer button to print the report.
- Click the Close button to close the report and access the Trace CAD/PAD system.

NOTE: Until all expired assets are removed from the system, this report will display each time the system is accessed.



Audio:

If expired assets are found in the system, a report will display. The expired assets report may be printed and must be closed before continuing.

Trace CAD/PAD Sections

View | Lots

•To view step-by-step training, click a topic below.

DODICS

Installs


Bu/Sers

Squadrons

Maintenance

Reports

Help




Audio:

Click a CAD/PAD training topic to access training for that section.

Accessing DODIC Information

View | Lots

- To access DODIC information, click the DODIC(S) button from the Main Menu.



Audio:

The DODIC section of the VFS Trace application provides read-only access to DODIC information. Click the DODIC(s) button from the Main Menu to access DODIC information.

Developer Notes

12/30/2002


DODICs.ppt

7

DODIC Menu Options

View | Lots

- The VFS - CAD/PAD : DODIC Screen will display.
- To view the training, click the Next arrow for sequential order or click a step-by-step training topic from the menu at the top of the screen.



Audio:

Training for the DODIC section may be viewed sequentially by using the Next arrow at the bottom right of this window. Training may also be viewed section by section using the menu at the top of this screen.

Developer Notes

12/30/2002



DODICs.ppt

8

View DODIC Information (Screen 1 of 4)

View | Lots

- Select a DODIC (the default) or part number to view technical data.
- To search by DODIC, type a valid DODIC in the DODIC box or click a DODIC from the list.



Audio:

To view a DODIC's information, you must select a DODIC (the system default) or part number. Click a DODIC in the DODIC list to view its information or type a valid DODIC in the box.

Developer Notes

12/30/2002



DODICs.ppt

9

View DODIC Information (Screen 2 of 4)

View | Lots

- To search by part number, clear the SEARCH BY DODIC check box.
- In the PART NUMBER list, click a part number.



Audio:

To search by part number instead of DODIC, click the check box next to Search by DODIC to clear it. Click a part number from the part number list to view its information.

Developer Notes

12/30/2002

DODICs.ppt

10

View DODIC Information (Screen 3 of 4)

View | Lots

- If the selected DODIC or part number has an exception, the associated exception data will display.
- If the aircraft is listed in the exception, the exception applies to that TMS.
- Similarly, the exception applies only to the range of lot numbers displayed.
- Use the scroll bar to scroll through the exceptions.

The screenshot shows a web application window titled "VFS - CAD/PAD : DODIC Screen". The window has a menu bar with "Find", "Edit", "Add", "Cancel", "Delete", "Save", and "Help". Below the menu bar, there is a search area with a "DODIC:" dropdown menu set to "XW53" and a checked box for "SEARCH BY DODIC". The "PART NUMBER:" field contains "850AS135". The "NOMENCLATURE:" field contains "EXPL SEQ CONTR". The "DEVICE:" field contains "CAD". The "SHELF LIFE:" field contains "156" and the "SERVICE LIFE:" field contains "84". The "W.U.C.:" field contains "97D3Z". Below the search area is a table titled "EXCEPTIONS:" with the following data:

DODIC	FROM LOT NO.	TO LOT NO.	AIRCRAFT	SHELF	SERV.
XW53	MSV*000-000	MSV*999-999	T-45A	156	24
XW53	ETI*000-000	ETI*999-999	T-45C	156	18
XW53	MSV*000-000	MSV*999-999	T-45C	156	24



Audio:

Lot number or aircraft T-M-S exceptions for the selected DODIC or part number will display. Exceptions apply to the lot numbers and aircraft displayed in the table. Rows with blank aircraft apply to all.

Developer Notes

12/30/2002

DODICs.ppt

11

View DODIC Information (Screen 4 of 4)

View | Lots

- If the selected DODIC or part number is a set DODIC, its members will display.

The screenshot shows a web application window titled "VFS - CAD/PAD : DODIC Screen". The interface includes a search bar with "4W24" entered, a "SEARCH BY DODIC" checkbox, and fields for "PART NUMBER: 837AS186", "NOMENCLATURE: MDC SET", "SHELF LIFE: 108", "SERVICE LIFE: 60", and "W.U.C.: 97B2Y". A table below displays the members of the set DODIC '4W24'.

DODIC	QTY	PRIMARY PART NUMBER	NOMENCLATURE	SHELF	SERV.
SU46	1	837AS179	FWD MDC ASSY	108	60
SU47	1	837AS180	FWD MDC ASSY	108	60
SU48	1	837AS181	AFT MDC ASSY	108	60
SU49	1	837AS182	AFT MDC ASSY	108	60




Audio:

When a DODIC or part number is a set, the members will display at the bottom of the screen.

Lots Information (Screen 1 of 2)

View | Lots

- Click the LOTS button on the left-hand side of the screen to view all lots for the selected DODIC or part number.



Audio:

Click the LOTS button located on the left-hand side of the screen to display all lots associated with the selected DODIC or part number.

Developer Notes

12/30/2002

DODICs.ppt

13

Lots Information (Screen 2 of 2)

View | Lots

- In the LOTS list, click a lot number to display its specific information.

The screenshot shows the 'VFS - CAD/PAD : DODIC Screen' interface. It includes a search bar with 'Find Edit Add Cancel Delete Save Help' buttons. The search criteria are: DODIC: XW53, PART NUMBER: 850AS135, NOMENCLATURE: EXPL SEQ CONTR, DEVICE: CAD, SHELF LIFE: 156, SERVICE LIFE: 84, and W.U.C.: 97D3Z. Below the search criteria is an 'EXCEPTIONS' table:

DODIC	FROM LOT NO.	TO LOT NO.	AIRCRAFT	SHELF	SERV.
XW53	MSV*000-000	MSV*999-999	T-45A	156	24
XW53	ETI*000-000	ETI*999-999	T-45C	156	18
XW53	MSV*000-000	MSV*999-999	T-45C	156	24

Below the exceptions table is a 'LOTS' dropdown menu with the following items: ETI91M004010, ETI93M005-011 (highlighted), MSV98H001-001, MSV98H001001, OAC00A001011, OAC11, OAC95E006-012, and OAC95K006-013. The 'MFG. DATE' field is empty. The interface also features a 'NAVSEA' logo and 'LOTS' and 'RETURN' buttons.



Audio:

Click a lot from the list to view the associated manufacture date.

Developer Notes

12/30/2002

DODICs.ppt

14

Main Menu (Installed Assets)

View | Lots

- To access installed asset information, click the **INSTALLS** button from the VFS Trace Main Menu.
- The **VFS - CAD/PAD Installed Assets** screen will display.



Audio:

Click the **Installs** button from the Main Menu located on the left-hand side of the screen to access installed asset information.

Developer Notes

12/30/2002

DODICs.ppt

15

Installs View on Entrance

View | Lots

- Squadron information will display based on your logon ID.
- To view the training, click the Next arrow for sequential order or click a step-by-step training topic from the menu at the top of the screen.

The screenshot shows a web browser window titled "Installed, ver 1.0.0.2 - Connected from: http://cadpadvfs". The main content area is titled "VFS - CAD/PAD Installed Assets" and features a menu on the left with buttons for "REPLACE", "BU/SER ASSETS", "LOCKER", "LOGBOOK", and "RETURN". The main form contains various input fields and dropdown menus for asset information, including:

- SQUADRON: [text box]
- ORGANIZATION CODE: AC1
- BU/SER: [dropdown]
- MODEX: [dropdown]
- AIRCRAFT: [text box]
- SEAT NUMBER: [text box]
- SEAT PART NO.: [text box]
- SEAT DESIG: [text box]
- SEAT SERIAL: [text box]
- DODIC: [text box]
- PART NUMBER: [text box]
- LOT: [text box]
- SHELF LIFE: [text box]
- SERV.: [text box]
- SERIAL NO.: [text box]
- NOMENCLATURE: [text box]
- LOCATION CODE: [text box]
- MFG. DATE: --
- LOCATION: [text box]
- OPEN. DATE: --
- MAINTENANCE ORG. CODE: [text box]
- INSTALL DATE: --
- EXPIRE DATE: --
- EXTEND DATE: --
- EXTENDED MONTH(S): [text box]
- FLEET COMMENTS: [text box]
- REASON: [text box]



Audio:

Your organization code will display automatically based on your logon ID.

Training for the installed assets section may be viewed sequentially by using the Next button at the bottom right of this window or section by section using the menu at the top of the screen.

Developer Notes

12/30/2002

DODICs.ppt

16

Finding an Installed Asset (Screen 1)

View | Lots

- To search for an installed asset, you must select a Bu/Ser.
- Squadrons will have access to Bu/Sers for which they have custody.
- TYCOMs and Wings will have access to all Bu/Sers assigned to squadrons under their cognizance.
- In the Bu/Ser list, click a Bu/Ser, or type a specific Bu/Ser number in the box.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

NAVSEA
INTEGRATED
Surface Warfare Center Division
CAD/PAD

REPLACE
BU/SER ASSETS
LOCKER
LOGBOOK
RETURN

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

SQUADRON: ORGANIZATION CODE: AC1

BU/SER: MODEX: AIRCRAFT:

SEAT NO: 123456 SEAT PART NO:

SEAT DE: 159592 SEAT SERIAL:

DODIC: 159603 PART NUMBER:

LOT: 161274 SHELF LIFE: SERV.

SERIAL: 161416 NOMENCLATURE:

LOCATION CODE: MFG. DATE: --

LOCATION: OPEN. DATE: --

MAINTENANCE ORG. CODE: INSTALL DATE: --

FLEET COMMENTS: EXPIRE DATE: --

REASON: EXTEND DATE: --

EXTENDED MONTH(S):



Audio:

Squadrons will have access to Bu/Sers for which they have custody.

TYCOM and Wing users will have access to all Bu/Sers assigned to squadrons under their cognizance.

Click a Bu/Ser in the Bu/Ser list or type a specific Bu/Ser number in the box.

Developer Notes

12/30/2002

DODICs.ppt

17

Finding an Installed Asset (Screen 2)

View | Lots

- The Bu/Ser assets are collected automatically.

LOC.	DODIC	PART NUMBER	LOT NUMBER	SERIAL	OPENED	INSTALL	EXPIRE	E
P01	SWDR	MBEU142229	MBA97L001041	070641	00-06-30	00-06-30	05-05-31	
P02	MT07	MBEU142229	MBA96D007015	211	99-12-31	99-12-31	04-12-31	
P03	MT13	MBEU146255	MBA97L010022	018	99-12-31	99-12-31	05-12-31	
P04	MT13	MBEU146255	MBA97L010022	001	99-12-31	99-12-31	05-12-31	
P05	MT18	MBEU146448	OAC98D001001A	172	01-04-30	01-04-30	03-04-30	
P06	MT29	MBEU146190	MBA99J004016	1530	01-09-24	01-09-24	06-09-30	
P07	MT30	MBEU142801	UPC948003H006	5090	01-09-24	01-09-24	09-02-28	
P08	MT88	MBEU145899	MBA95K007016	302	99-12-31	99-12-31	04-10-31	



Audio:

When a Bu/Ser is selected, the assets associated with the Bu/Ser will be collected automatically.

Developer Notes

12/30/2002

DODICs.ppt

18

Finding an Installed Asset (Screen 3)

View | Lots

- Click the Find button to display the FIND window.
- You may search for installed assets by DODIC, lot number, or part number.
- Select the check box next to the desired search type and type the appropriate search information in the FIND field.
- Hit Enter on your keyboard.

LOC.	DODIC	PART NUMBER	LOT NUMBER	SERIAL	OPENED	INSTALL	EXPIRE	E.A.
P01	CWDR	MBEU147990	MBA97L001041	DP0641	00-06-30	00-06-30	05-05-31	
P02	MT07	MBEU142229	MBA96D007015	211	99-12-31	99-12-31	04-12-31	
P03	MT13	MBEU146255	MBA97L010022	018	99-12-31	99-12-31	05-12-31	
P04	MT13	MBEU146255	MBA97L010022	001	99-12-31	99-12-31	05-12-31	
P05	MT18	MBEU146448	OAC98D001001A	172	01-04-30	01-04-30	03-04-30	
P06	MT29	MBEU146190	MBA99J004016	1538	01-09-24	01-09-24	06-09-30	
P07	MT30	MBEU142801	UPC8480030006	5090	01-09-24	01-09-24	09-02-28	
P08	MT88	MBEU145999	MBA95K007016	302	99-12-31	99-12-31	04-10-31	



Audio:

Click the Find button from the menu at the top of the screen to locate an installed asset by DODIC, lot number, or part number. Select the type of search item, type the find information, and hit Enter to search for the installed asset.

Developer Notes

12/30/2002

DODICs.ppt

19

Finding an Installed Asset (Screen 4)

View | Lots

- If an item matches your search criteria, it will highlight in blue.
- Click the Find button again to close the Find window.

NOTE: Clicking the BU/SER ASSETS button toggles the table on and off.

LOC.	DODIC	PART NUMBER	LOT NUMBER	SERIAL	OPENED	INSTALL	EXPIRE	E
P01	CWDR	MBEU147990	MBA97L001041	DF0641	00-06-30	00-06-30	05-05-31	
P02	MT07	MBEU142229	MDA96D007015	211	99-12-31	99-12-31	04-12-31	
P03	MT13	MBEU146255	MBA97L010022	018	99-12-31	99-12-31	05-12-31	
P04	MT13	MBEU146255	MBA97L010022	001	99-12-31	99-12-31	05-12-31	
P05	MT18	MBEU146448	OAC98D001001A	172	01-04-30	01-04-30	03-04-30	
P06	MT29	MBEU146190	MDA99J004016	1530	01-09-24	01-09-24	06-09-30	
P07	MT30	MBEU142801	LJFC486003-0106	5080	01-09-24	01-09-24	09-02-28	
P08	MT88	MBEU148399	MBA99K007016	302	99-12-31	99-12-31	04-10-31	



Audio:

If the search item is found, it will highlight in blue. Click the Find button again to close the Find window.

Developer Notes

12/30/2002

DODICs.ppt

20

Finding an Installed Asset (Screen 5)

View | Lots

- To view additional installed asset information, select an installed asset by double-clicking anywhere in the row or by selecting a row and hitting Enter.
- The data table will close and data associated with the selected installed asset will display in the main screen.

LOC	DODIC	PART NUMBER	LOT NUMBER	SERIAL	OPENED	INSTALL	EXPIRE
P01	CWDR	MBEU147990	MBA97L001041	DP0641	00-06-30	00-06-30	05-05-31
P02	MT07	MBEU142229	MBA96D007015	211	99-12-31	99-12-31	04-12-31
P03	MT13	MBEU146255	MBA97L010022	018	99-12-31	99-12-31	05-12-31
P04	MT13	MBEU146255	MBA97L010022	001	99-12-31	99-12-31	05-12-31
P05	MT18	MBEU146448	OAC98D001001A	172	01-04-30	01-04-30	03-04-30
P06	MT29	MBEU146190	MBA99J004016	1538	01-09-24	01-09-24	06-09-30
P07	MT30	MBEU142801	LPC346003H006	5080	01-09-24	01-09-24	09-02-28
P08	MT36	MBEU145999	MBA99K007016	302	99-12-31	99-12-31	04-12-31



Audio:

A specific installed asset can be displayed individually by double-clicking, or hitting the enter key, on the desired item in the installed assets table.

Developer Notes

12/30/2002

DODICs.ppt

21

Editing an Installed Asset (Screen 1)

View | Lots

- To edit an installed asset, find the installed asset and click Edit from the menu at the top of the screen.
- Green indicates fields that can be modified. White and yellow fields are read-only.

NOTE: The edit function is not intended to be used as the replacement function for an installed asset.

Installed, ver 1.0.0.2 - Connected from: http://cadpadvts

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

REPLACE SQUADRON: VF-101 ORGANIZATION CODE: AC1

Installed, ver 1.0.0.2 - Connected from: http://cadpadvts

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

SQUADRON: VF-101 ORGANIZATION CODE: AC1

BU/SER: 159592 MODEX: AIRCRAFT: F-14D

SEAT NUMBER: 1 SEAT PART NO: SJJU-17-V-3/A

SEAT DESIG: PILOT SEAT SERIAL: PSZ054

DODIC: MT88 PART NUMBER: MBEU145899

LOT: MBA95K007016 SHELF LIFE: 108 SERV. 72

SERIAL NO.: 302 NOMENCLATURE: IMPULSE CART

LOCATION CODE: P08 MFG DATE: 95-10-31

LOCATION: DROGUE RELEASE OPEN DATE: 99-12-31

MAINTENANCE ORG. CODE: AC1 INSTALL DATE: 99-12-31

FLEET COMMENTS: EXPIRE DATE: 04-10-31

REASON: EXTEND DATE: - -

EXTENDED MONTH(S): 0

Audio:

The Edit function is used for correction of previously entered data. It is not intended to be used as the replacement function for an installed asset. To edit an installed asset's information, use the Find option to locate the installed asset. Then click Edit to make changes to the item. The background color for information that may be modified will highlight green. White and yellow fields are read-only.

Developer Notes

12/30/2002

DODICs.ppt

22

Editing an Installed Asset (Screen 2)

View | Lots

- If the lot number is not in standard format or does not exist in the master lot table, a warning will prompt you to accept the lot number.
- Click No to correct the lot. Click Yes to notify Indian Head of the new lot number for validation.

Installed, ver 1.0.0.2 - Connected from: http://cadpadvfs

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

SQUADRON: VF-101 ORGANIZATION CODE: AC1

BU/SER: 159592 MODEX: AIRCRAFT: F-14D

SEAT NUMBER: 1 SEAT PART NO.: SJU-17-V-3/A

SEAT DESIG: PILOT SEAT SERIAL: PSZ054

DODIC: MT88 PART NUMBER: MBEU145899

LOT: MBAS5K0 **INSTALLS REPLACE Lot Number** LIFE: 108 SERV. 72

SERIAL NO.: Invalid lot number or format! MFG. DATE: 95-10-31

LOCATION CODE: Accept lot and format anyway? OPEN. DATE: 99-12-31

LOCATION: DR INSTALL DATE: 95-12-31

MAINTENANCE: EXPIRE DATE: 04-10-31

EXTEND DATE: --

EXTENDED MONTH(S): 0

FILET COMMENTS:

REASON:



Audio:

Lot number format will be verified when an item is edited. If the format is not correct or if the lot number does not exist in the master lot table, you will be prompted to accept or correct the lot number.

Developer Notes

12/30/2002

DODICs.ppt


23

Editing an Installed Asset (Screen 3)

View | Lots

The system will validate the date fields to ensure the following conditions are met:

- Open date must be after manufacture date
- Open date cannot be later than the current date.
- Install date must be the same or later than the open date.
- Install date cannot be later than the current date.



Audio:

The system will validate the date fields and report errors. Errors must be corrected before the changes can be saved.

Developer Notes

12/30/2002

DODICs.ppt

24

Editing an Installed Asset (Screen 4)

View | Lots

- To save the installed asset changes, click Save from the menu at the top of the screen.
- To cancel changes, click Cancel.

Note: Service Life Calculation/Recalculation will be performed each time changes are saved.

Installed, ver 1.0.0.2 - Connected from: http://cadpadvfs

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

NAVSEA
INTEGRATED AIR
Surface Warfare Center Division
CAD/PAD

REPLACE

BU/SER ASSETS

LOCKER

LOGBOOK

RETURN

SQUADRON: VF-101 ORGANIZATION CODE: AC1

BU/SER: 159592 MODEX: AIRCRAFT: F-14D

SEAT NUMBER: 1 SEAT PART NO.: SJJU-17-V-3/A

SEAT DESIG: PILOT SEAT SERIAL: PSZ054

DODIC: MT88 PART NUMBER: MBEU145899

LOT: MBA95K007019 SHELF LIFE: 108 SERV.: 72

SERIAL NO.: 302 NOMENCLATURE: IMPULSE CART

LOCATION CODE: P08 MFG. DATE: 95-10-31

LOCATION: DROGUE RELEASE OPEN. DATE: 99-12-31

MAINTENANCE ORG. CODE: AC1 INSTALL DATE: 99-12-31

EXPIRE DATE: 04-10-31

EXTEND DATE: --

EXTENDED MONTH(S): 0

FLEET COMMENTS:

REASON:



Audio:

After editing an installed asset's information, click Save to save your changes or Cancel to end the process without saving changes.

Developer Notes

12/30/2002

DODICs.ppt

25

Replace an Installed Asset (Screen 1)

View | Lots

- The Replace function allows you to move an asset to a ready service locker and/or replace an asset with a replacement asset.
- **Find the Installed Asset** to be replaced. Select the installed asset to be replaced from the Installed Asset table.
- Select the REPLACE button on the left-hand side of the screen.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

NAVSEA
HUMAN HEAD
EUROPE/WESTERN CENTRAL DIVISION
CAD/PAD

REPLACE
BU/SER ASSETS
LOCKER
LOGBOOK
RETURN

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

SQUADRON: VF-101 ORGANIZATION CODE: AC1
BU/SER: 159592 MODEX: AIRCRAFT: F-14D
SEAT NUMBER: 1 SEAT PART NO: SJU-17-V-3/A
SEAT DESIG: PILOT SEAT SERIAL: PSZ054
DODIC: MT88 PART NUMBER: MBEU145899
LOT: MBA95K007019 SHELF LIFE: 108 SERV: 72
SERIAL NO.: 302 NOMENCLATURE: IMPULSE CART
LOCATION CODE: P08 MFG. DATE: 95-10-31
LOCATION: DROGUE RELEASE OPEN. DATE: 99-12-31
MAINTENANCE ORG. CODE: AC1 INSTALL DATE: 99-12-31
EXPIRE DATE: 04-10-31
EXTEND DATE: --
EXTENDED MONTH(S): 0
FLEET COMMENTS:
REASON:

Audio:

The Replace function provides a means to place an asset in the ready service locker and to optionally replace an item with another item. To replace an installed asset, first find the Bu/Ser on which the asset is located. Next, click the Replace button located on the left-hand side of the screen.

Developer Notes

12/30/2002

DODICs.ppt

26

Replace an Installed Asset (Screen 2)

View | Lots

- A message will prompt you to choose whether or not to store the asset in the ready service locker without installing a replacement asset.

Installed, ver 1.0.0.2 - Connected from: http://cndpadvfs

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

SQUADRON: VF-101 ORGANIZATION CODE: AC1

BU/SER: 159592 MODEX: AIRCRAFT: F-14D

SEAT NUMBER: 1 SEAT PART NO.: SJU-17-V-3/A

SEAT DESIG: PILOT SEAT SERIAL: PSZ054

DODIC: MT88 PART NUMBER: MBEU145899

INSTALS Asset Extraction - Mission Related...

Do you wish to move this asset [DODIC: MT88] to the 'Ready Service Locker' without installing a replacement asset?

Yes No

SERV. 72

SE CART

95-10-31

99-12-31

99-12-31

04-10-31

EXTEND DATE: - -

EXTENDED MONTH(S): 0

FLEET COMMENTS:

REASON:



Audio:

You will be prompted whether or not to store the asset in the ready service locker without installing a replacement asset.

Developer Notes

12/30/2002

DODICs.ppt

27

Replace an Installed Asset (Screen 3)

View | Lots

- Click Yes to store the asset in the ready service locker without replacement. This will not generate an asset-for-asset replacement.

NOTE: Blank lot number, serial number, and date fields indicate the asset is located in the ready service locker.

Installed, ver 1.0.0.2 - Connected from: http://cadpadvfs

NAVSEA
INTEGRATED
Surface Warfare Center Division
CAD/PAD


REPLACE
BU/SER ASSETS
LOCKER
LOGBOOK
RETURN

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

SQUADRON: VF-101 ORGANIZATION CODE: AC1
BU/SER: 159592 MODEX: AIRCRAFT: F-14D
SEAT NUMBER: 1 SEAT PART NO: SJJ-17-V-3/A
SEAT DESIGN: PILOT SEAT SERIAL: PSZ054
DODIC: MT88 PART NUMBER: MBEU145899
LOT: SHELF LIFE: 108 SERV: 72
SERIAL NO.: NOMENCLATURE: IMPULSE CART
LOCATION CODE: P08 MFG. DATE: --
LOCATION: DROGUE RELEASE OPEN DATE: --
MAINTENANCE ORG. CODE: INSTALL DATE: --
EXPIRE DATE: --
EXTEND DATE: --
EXTENDED MONTH(S): 0

FLEET COMMENTS:
REASON:



Audio:

If you click Yes, an asset-for-asset replacement does not occur and the replacement process is ended. The installed asset's information is moved to the ready service locker.

Developer Notes

12/30/2002

DODICs.ppt

28

Replace an Installed Asset (Screen 4)

View | Lots

- If you choose to store the item in the ready service locker without installing a replacement asset, you will be prompted whether or not to replace the current asset with another.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

NAVSEA
NORTH PACIFIC
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

SQUADRON: VF-101 ORGANIZATION CODE: AC1

BU/SER: 159592 MODEX: AIRCRAFT: F-14D

SEAT NUMBER: 2 SEAT PART NO: SJU-17-V-4/A

SEAT DESIG: NFO SEAT SERIAL: PSZ054

DODIC: MT88 PART NUMBER: MBEU145899

LOT: MBAGSK007016 SERIAL NO: REPLACE - Asset Replacement LOCATION: 108 SERVIC: 72

Do you wish to replace the specified asset with another one?

Yes No

IMPULSE CART

EXP. DATE: 95-10-31

IN. DATE: 99-12-31

INSTALL DATE: 99-12-31

EXPIRE DATE: 04-10-31

EXTEND DATE: - -

EXTENDED MONTH(S): 0

FLEET COMMENTS:

REASON:



Audio:

If you click No, you will be prompted to indicate whether or not you wish to replace the current asset with another asset. Click No to end the replacement process.

Developer Notes

12/30/2002

DODICs.ppt

29

Replace an Installed Asset (Screen 5)

View | Lots

- If you choose not to replace the current asset with another, you will be prompted again to indicate whether or not to remove the asset without installing a new asset.
- If you click No, the replacement process will end.

Installed, ver 1.0.0.2 - Connected from: http://cadpadofs

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

NAVSEA
INTEGRATED ASSET
SERVICES & SUPPORT SYSTEM DIVISION
CAD/PAD

REPLACE
BU/SER ASSETS
LOCKER
LOGBOOK
RETURN

SQUADRON: VF-101 ORGANIZATION CODE: AC1
BU/SER: 159592 MODEX: AIRCRAFT: F-14D
SEAT NUMBER: 2 SEAT PART NO: SJU-17-V-4/A
SEAT DESIGN: NFO SEAT SERIAL: PSZ054
DODIC: MT88 PART NUMBER: MBEU145899
LOT: MR895K07046 108 SERV. 72
SERIAL N: REPLACE - Asset Removal
Do you wish to remove this asset without installing a new asset?
LOCATIC: Yes No
LOCATIC: MPULSE CART
MAINTENANCE ORG. CODE: AC1 INSTALL DATE: 99-12-31
EXPIRE DATE: 04-10-31
EXTEND DATE: - -
EXTENDED MONTH(S): 0
FLEET COMMENTS:
REASON:



Audio:

If you click No, you will be prompted again whether or not to remove the asset without installing a new asset. Select No to end the replace process.

Developer Notes

12/30/2002

DODICs.ppt

30

Replace an Installed Asset (Screen 6)

View | Lots

- If you click Yes, the replaced item will be removed from the installed assets.
- Editable fields for the replacement asset will highlight green.

Installed, ver 1.0.0.2, Connected from: http://cadpnavfs

NAVSEA
INFORM HEAD
Surface Warfare Center Division
CAD/PAD

REPLACE
BU/SER ASSETS
LOCKER
LOGBOOK
RETURN

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

SQUADRON: VF-101 ORGANIZATION CODE: AC1
BU/SER: 159592 MODEX: AIRCRAFT: F-14D
SEAT NUMBER: 2 SEAT PART NO.: SJU-17-V-4/A
SEAT DESIG: NFO SEAT SERIAL: PSZ054
DODIC: MT88 PART NUMBER: MBEU145899
LOT: SHELF LIFE: 108 SERV.: 72
SERIAL NO.: NOMENCLATURE: IMPULSE CART
LOCATION CODE: N08 MFG. DATE: - -
LOCATION: DROGUE RELEASE OPEN. DATE: - -
MAINTENANCE ORG. CODE: AC1 INSTALL DATE: - -
EXPIRE DATE: - -
EXTEND DATE: - -
EXTENDED MONTH(S): 0
FLEET COMMENTS:
REASON:



Audio:

If you click Yes, editable fields will highlight green indicating replacement information can be entered.

Developer Notes

12/30/2002

DODICs.ppt

31

Replace an Installed Asset (Screen 7)

View | Lots

- If more than one DODIC can be used for replacement, click the DODIC to be used in the replacement from the list.
- The government-preferred part number for that item will display. Available alternate part numbers will be listed in the part number list.

Installed, ver 1.0.0.2 - Connected from: http://cadpadvfs

NAVSEA
INTEGRATED
Surface Warfare Center Division
CAD/PAD

REPLACE
BU/SER ASSETS
LOCKER
LOGBOOK
RETURN

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

SQUADRON: VF-101 ORGANIZATION CODE: AC1
BU/SER: 159592 MODEX: AIRCRAFT: F-14D
SEAT NUMBER: 0 SEAT PART NO: N/A
SEAT DESIGN: N/A SEAT SERIAL: N/A
DODIC: SR65 PART NUMBER: 841AS425-1052
LOT: MB40 SHELF LIFE: 192 SERV. 108
SERIAL NO.: NOMENCLATURE: SMDC
LOCATION CODE: 138 MFG. DATE: --
LOCATION: 251 OPEN DATE: --
MAINTENANCE ORG. CODE: AC1 INSTALL DATE: --
EXPIRE DATE: --
EXTEND DATE: --
EXTENDED MONTH(S): 0

FLEET COMMENTS:
REASON:



Audio:

In the DODIC list, click the DODIC to be used as the replacement. The system automatically displays the government-preferred part number.

Developer Notes

12/30/2002

DODICs.ppt

32

Replace an Installed Asset (Screen 8)

View | Lots

- Click the lot number from the LOT list, or type a lot number in the box.
- The manufacturing date for that lot will display.
- If the lot number is not in standard format or does not exist in the master lot table, a warning will display prompting you to accept the lot number.
- Click No to correct the lot. Click Yes to notify Indian Head of the new lot number for validation.

Installed, ver 1.0.0.2 - Connected from: http://cndpadvfs

NAVSEA
NATIONAL SURFACE WARFARE CENTER DIVISION
CAD/PAD

REPLACE
BU/SER ASSETS
LOCKER
LOGBOOK
RETURN

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help

SQUADRON: VF-101 ORGANIZATION CODE: AC1
BU/SER: 159592 MODEX: AIRCRAFT: F-14D
SEAT NUMBER: 0 SEAT PART NO.: N/A
SEAT DESIG: N/A SEAT SERIAL: N/A
DODIC: SR65 PART NUMBER: 841AS425-1052
LOT: MSV94C007020 SHELF LIFE: 192 SERV.: 108
SERIA: MSV94E008002 NOMENCLATURE: SMDC
LOCA: MSV84J004002 MFG. DATE: -
LOCA: MSV96F009005 OPEN. DATE: -
MAIN: MSV96F009007 INSTALL DATE: -
(MSV96F009010) EXTEND DATE: -
(MSV98G010004) EXTENDED MONTH(S): 0
(MSV99C011006)

FLEET COMMENTS:
REASON:



Audio:

In the LOT list, click the lot number for the replacement item. The system will display the lot manufacturing date automatically. If the lot number format is incorrect or if it does not exist in the master lot table, a message will display.

Developer Notes

12/30/2002

DODICs.ppt

33

Replace an Installed Asset (Screen 9)

View | Lots

- The lot number, serial number, and date fields highlighted in green are mandatory entries.
- Use the Enter or Tab key to move from one field to the next.
- The maintenance organization code will default to the command having custody.
- Complete your editing changes.

NOTE: The sequence of field editing is very important. Entering fields out of order could result in error.

Audio:

You must type or click values for serial number, lot number, and date fields. Use the Enter or Tab key to move from one field to the next. The sequence of field editing is very important. Entering fields out of order could result in error.

Developer Notes

12/30/2002

DODICs.ppt


34

Replace an Installed Asset(Screen 10)

View | Lots

The system will validate the date fields to ensure the following conditions are met:

- Open date must be after manufacture date
- Open date cannot be later than the current date.
- Install date must be the same or later than the open date.
- Install date cannot be later than the current date.



Audio:

The system will validate the date fields and report errors. Errors must be corrected before the changes can be saved.

Developer Notes

12/30/2002

DODICs.ppt

35

Replace an Installed Asset (Screen 11)

View | Lots

- Click Save from the menu at the top of the screen to save your changes.
- Service Life Calculation/Recalculation is performed each time changes are saved.



Audio:

Click Save to save your changes or Cancel to abort.

Developer Notes

12/30/2002

DODICs.ppt

36

Replace an Installed Asset (Screen 12)

View | Lots

- On completion, the Installed Assets table will display.

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

SQUADRON: VF-101 ORGANIZATION CODE: AC1
BU/SER: 159592 MODEX: AIRCRAFT: F-14D
SEAT NUMBER: 0 SEAT PART NO: N/A
SEAT DESIGN: N/A SEAT SERIAL: N/A
DODIC: SR65 PART NUMBER: 841AS425-1052
LOT: MSV96F009005 SHELF LIFE: 192 SERV. 108
SERIAL NO.: 59871 NOMENCLATURE: SMDC
LOCATION CODE: 138 MFG. DATE: 96-06-30
LOCATION: 251 OPEN. DATE: 02-05-19

LOC.	DODIC	PART NUMBER	LOT NUMBER	SERIAL	OPENED	INSTALL	EXPIRE	E
220	SR58	841AS425-1040	MSV99C011006	5784	01-04-30	01-04-30	10-04-30	
221	SR59	841AS425-1041	MSV99C011006	5796	01-04-30	01-04-30	10-04-30	
222	SR60	841AS425-1042	MSV99C011006	5815	01-04-30	01-04-30	10-04-30	
201	SR61	841AS425-1043	MSV99C011004	5839	01-04-30	01-04-30	10-04-30	
202	SR62	841AS425-1044	MSV99C011006	5855	01-04-30	01-04-30	10-04-30	
209	SR63	841AS425-1050	MSV99C011006	5872	01-04-30	01-04-30	10-04-30	
116	SR64	841AS425-1051	MSV99C011006	5802	01-04-30	01-04-30	10-04-30	
138	SR65	841AS425-1052	MSV96F009005	59871	02-05-19	02-08-15	11-05-31	



Audio:

Once the replacement is complete, the Installed Assets Table will display.

Developer Notes

12/30/2002

DODICs.ppt

37

Bu/Ser Assets (Screen 1)

View | Lots

- The Bu/Ser assets function displays installed assets for the current Bu/Ser.
- To view installed assets, you must first [find a Bu/Ser](#).
- When a Bu/Ser displays, click the BU/SER ASSETS located on the left-hand side of the screen to display the Installed Assets table.
- Click the BU/SER ASSETS button again to hide the table.

LOC.	DODIC	PART NUMBER	LOT NUMBER	SERIAL	OPENED	INSTALL	EXPIRE	E--
220	SR58	841AS425-1040	MSV99C011006	5784	01-04-30	01-04-30	10-04-30	
221	SR59	841AS425-1041	MSV99C011006	5796	01-04-30	01-04-30	10-04-30	
222	SR60	841AS425-1042	MSV99C011006	5815	01-04-30	01-04-30	10-04-30	
201	SR61	841AS425-1043	MSV99C011004	5839	01-04-30	01-04-30	10-04-30	
202	SR62	841AS425-1044	MSV99C011006	5855	01-04-30	01-04-30	10-04-30	
209	SR63	841AS425-1050	MSV99C011006	5872	01-04-30	01-04-30	10-04-30	
116	SR64	841AS425-1051	MSV99C011006	5902	01-04-30	01-04-30	10-04-30	
138	SR65	841AS425-1052	MSV96F009005	59871	02-05-19	02-08-15	11-05-31	



Audio:

The Bu/Ser assets function displays installed assets for a specific Bu/Ser. To view a Bu/Ser's assets, the user must first select a Bu/Ser and then click the Bu/Ser Assets button.

Developer Notes

12/30/2002

DODICs.ppt

38


Bu/Ser Assets (Screen 2)

View | Lots

- An installed assets table will display across the bottom of the screen.
- The assets will display in configuration order.

Note: The table may take a minute to load depending on the number of installed assets on the Bu/Ser.

LOC.	DODIC	PART NUMBER	LOT NUMBER	SERIAL	OPENED	INSTALL	EXPIRE	E
220	SR58	841AS425-1040	MSV99C011006	5784	01-04-30	01-04-30	10-04-30	
221	SR59	841AS425-1041	MSV99C011006	5796	01-04-30	01-04-30	10-04-30	
222	SR60	841AS425-1042	MSV99C011006	5815	01-04-30	01-04-30	10-04-30	
201	SR61	841AS425-1043	MSV99C011004	5839	01-04-30	01-04-30	10-04-30	
202	SR62	841AS425-1044	MSV99C011006	5855	01-04-30	01-04-30	10-04-30	
209	SR63	841AS425-1050	MSV99C011006	5872	01-04-30	01-04-30	10-04-30	
116	SR64	841AS425-1051	MSV99C011006	5902	01-04-30	01-04-30	10-04-30	
138	SR65	841AS425-1052	MSV96F009005	59871	02-05-19	02-08-15	11-05-31	



Audio:

The Installed Assets table is organized in configuration order. This table may be used to browse through installed assets for the selected Bu/Ser.

Developer Notes

12/30/2002

DODICs.ppt

39

Bu/Ser Assets (Screen 3)

View | Lots

- To view additional installed asset information, select an installed asset by double-clicking anywhere in the row or by selecting a row and clicking Enter.

LOC.	DODIC	PART NUMBER	LOT NUMBER	SERIAL	OPENED	INSTALL	EXPIRE	E
220	SR58	841AS425-1040	MSV99C011006	5784	01-04-30	01-04-30	10-04-30	
221	SR59	841AS425-1041	MSV99C011006	5796	01-04-30	01-04-30	10-04-30	
222	SR60	841AS425-1042	MSV99C011006	5815	01-04-30	01-04-30	10-04-30	
201	SR61	841AS425-1043	MSV99C011004	5839	01-04-30	01-04-30	10-04-30	
202	SR62	841AS425-1044	MSV99C011006	5855	01-04-30	01-04-30	10-04-30	
209	SR63	841AS425-1050	MSV99C011006	5872	01-04-30	01-04-30	10-04-30	
116	SR64	841AS425-1051	MSV99C011006	5902	01-04-30	01-04-30	10-04-30	
138	SR65	841AS425-1052	MSV96F009005	59871	02-05-19	02-08-15	11-05-31	

Audio:

A specific installed asset can be displayed individually by double-clicking the desired item in the installed assets table.

Developer Notes

12/30/2002

DODICs.ppt

40

Bu/Ser Assets (Screen 4)

View | Lots

- The data table will close and data associated with the selected installed asset will display in the main screen.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help

SQUADRON: VF-101 ORGANIZATION CODE: AC1

BU/SER: 159592 MODEX: AIRCRAFT: F-14D

SEAT NUMBER: 0 SEAT PART NO.: N/A

SEAT DESIG: N/A SEAT SERIAL: N/A

DODIC: SR65 PART NUMBER: 841AS425-1052

LOT: MSV96F009005 SHELF LIFE: 192 SERV.: 108

SERIAL NO.: 59871 NOMENCLATURE: SMDC

LOCATION CODE: 138 MFG. DATE: 96-06-30

LOCATION: 251 OPEN. DATE: 02-05-19


MAINTENANCE ORG. CODE: AC1 INSTALL DATE: 02-08-15

EXPIRE DATE: 11-05-31

EXTENDED MONTH(S): 0

FLEET COMMENTS:

REASON:



Audio:

After selecting an asset, the table closes and asset information will display in the main screen.

Developer Notes

12/30/2002

DODICs.ppt

41

Locker (Screen 1)

View | Lots

- Click the LOCKER button to view assets in the ready service locker.

NOTE: The ready service locker stores mission-related assets that are currently uninstalled but not replaced with another asset. These assets are available for installation as required.

SQUADRON: VF-101 ORGANIZATION CODE: AC1
BU/SER: 159592 MODEX: AIRCRAFT: F-14D
SEAT NUMBER: 0 SEAT PART NO: N/A
SEAT DESIGN: N/A SEAT SERIAL: N/A
DODIC: SR65 PART NUMBER: 841AS425-1052
LOT: MSV96F009005 SHELF LIFE: 192 SERV. 108
SERIAL NO.: 59871 NOMENCLATURE: SMDC
LOCATION CODE: 138 MFG. DATE: 96-06-30
LOCATION: 251 OPEN. DATE: 02-05-19
MAINTENANCE ORG. CODE: AC1 INSTALL DATE: 02-08-15
EXPIRE DATE: 11-05-31
EXTEND DATE: - -
EXTENDED MONTH(S): 0
FLEET COMMENTS:
REASON:



Audio:

The Ready Service Locker was established to store mission-related assets that are currently uninstalled due to replacement, SDLM, or redesignation but not yet replaced with another asset. These assets are available for installation as required. To view assets in the locker, click the Locker button.

Developer Notes

12/30/2002

DODICs.ppt

42

Locker (Screen 2)

View | Lots

- The system displays the locker contents in a table.
- To close the locker table, click the LOCKER button again.

Note: The expiration dates of uninstalled assets contained in the ready service locker are automatically updated when **IRACs** are entered in the system.

Bu/Ser	DODIC	Part Number	Lot Number	Serial	Mfg. Date	Open Date	Expires	Extend
▶ 159592	MT88	MBELU145899	MBA95K007016	307	95-10-31	99-12-31	04-10-31	
159592	MT88	MBELU145899	MBA93C004010	598315	93-04-30	02-01-15	02-04-30	
159592	MT88	MBELU145099	MBA95K007019	302	95-10-31	99-12-31	04-10-31	
161422	M507	2520002	MBAB6J001030	N/A	86-09-30	00-10-30	08-09-30	
161422	M507	2520002	MBAB6H001029	32165898	86-08-31	92-09-18	02-09-30	
161422	M507	2520002	MBAB6H001029	954357	86-08-31	92-11-16	02-11-30	



Audio:

The system displays the locker contents in a table at the bottom of the screen.

Developer Notes

12/30/2002

DODICs.ppt

43

Locker (Screen 3)

View | Lots

- To view additional information about the asset, click the drop-down arrow in the Bu/Ser field located in the locker table.

NOTE: Click anywhere in the Bu/Ser field to display the drop-down arrow.

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

SQUADRON: _____ ORGANIZATION CODE: AC1

BU/SER: _____ MODEX: _____ AIRCRAFT: _____

SEAT NUMBER: _____ SEAT PART NO. _____

SEAT DESIG: _____ SEAT SERIAL: _____

DODIC: _____ PART NUMBER: _____

LOT: _____ SHELF LIFE: _____ SERVO: _____

SERIAL NO.: _____ NOMENCLATURE: _____

LOCATION CODE: _____ MFG. DATE: - -

LOCATION: _____ OPEN DATE: - -

Bu/Ser	DODIC	Part Number	Lot Number	Serial	Mfg. Date	Open Date	Expires	Extend
159592	MT88	MBELU45899	MBEA95K007016	307	95-10-31	99-12-31	04-10-31	
159592	MT88	MBELU45899	MBEA93D004010	598315	93-04-30	02-01-15	02-04-30	
159592	MT88	MBELU45099	MBEA95K007019	302	95-10-31	99-12-31	04-10-31	

PLATFORM LOC. LOCATION REASON

F-14D IP08 DROGUE RELEASE

161422 MSU/ 2520002 MBEA88H001029 954357 86-08-31 92-11-18 02-11-30

R.S.L. Expiration(s) R.S.L. Specific Asset Removal R.S.L. Maintenance R.S.L. Report



Audio:

You can view additional asset information by clicking the drop-down arrow in the Bu/Ser field in the Locker table.

Developer Notes

12/30/2002

DODICs.ppt

44

Locker (Screen 4)

View | Lots

- To display the assets color-coded by expiration date, select the R.S.L. Expiration(s) check box at the bottom of the screen.
- Select the R.S.L. Expiration(s) check box again to remove the color-coding.

Expiration Color Codes

- Red – assets that have expired
- Yellow – assets that expire within 120 days
- Green – all assets with expiration dates greater than 120 days

Bu/Ser	DODI	Part Number	Lot Number	Serial	Mfg Date	Open Date
159692	MT13	MBEU146255	MBA97LD10022	018	95-10-31	99-12-31
159692	MT13	MBEU146255	MBA97LD10022	032	95-10-31	99-12-31
159692	MT18	MBEU146448	OAC96D001001A	962	95-10-31	99-12-31
159692	MW74	841AS300	UPC91H001001	0180	95-10-31	99-12-31

NAVSEA
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD Installed

REPLACE
BU/SER ASSETS
LOCKER
LOGBOOK
RETURN

SQUADRON: _____ ORGANIZATION: _____
 BU/SER: _____ MODEX: _____
 SEAT NUMBER: _____ SEAT PART NO.: _____
 SEAT DESIG: _____ SEAT SERIAL: _____
 DODIC: _____ PART NUMBER: _____
 LOT: _____ SHELF LIFE: _____
 SERIAL NO.: _____ NOMENCLATURE: _____
 LOCATION CODE: _____ MFG. DATE: _____
 LOCATION: _____ OPEN DATE: _____

Bu/Ser	DODIC	Part Number	Lot Number	Serial	Mfg Date	Open Date
159692	MT08	MBEU145999	MBA96D007018	287	95-10-31	99-12-31
159692	MT08	MBEU145999	MBA96D007019	388014	95-10-31	99-12-31
159692	MT08	MBEU145999	MBA96D007019	382	95-10-31	99-12-31
161422	MS02	2520002	MBA96H001830	N/A	86-09-30	88-10-30
161422	MS07	2520002	MBA96H001829	32165939	86-09-31	92-09-18
161422	MS07	2520002	MBA96H001829	954357	86-08-31	92-11-16

R.S.L. Expiration(s) R.S.L. Specific Asset Removal R.S.L. Maintenance

Audio:

- To display the assets color-coded by expiration date, select the R.S.L. Expiration(s) check box at the bottom of the screen. Color-coded items will display based on the number of days left until they expire. Clear the R.S.L. Expiration(s) check box to remove the color coding.

Developer Notes

12/30/2002

DODICs.ppt

45

Locker (Screen 5)

View | Lots

- To flag an asset for removal from the locker, select the asset by clicking anywhere in that row.
- Select the R.S.L. Specific Asset Removal check box at the bottom of the screen.
- Assets flagged for deletion will highlight red.
- To unflag an item for removal, select the marked item by clicking anywhere in that row and then select the R.S.L. Specific Asset Removal check box.

Note: This option is used only to flag items for deletion. Flagged items will be deleted using the R.S.L. Maintenance option.

Installed, ver 1.0.0.2, Connected from: http://cadpadvts

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

SQUADRON: _____ ORGANIZATION CODE: AC1

BU/SER: _____ MODEX: _____ AIRCRAFT: _____

SEAT NUMBER: _____ SEAT PART NO. _____

SEAT DESIG: _____ SEAT SERIAL: _____

DODIC: _____ PART NUMBER: _____

LOT: _____ SHELF LIFE: _____ SERV. _____

SERIAL NO.: _____ NOMENCLATURE: _____

LOCATION CODE: _____ MFG. DATE: - -

LOCATION: _____ OPEN. DATE: - -

BuSer	DODIC	Part Number	Lot Number	Serial	Mfg. Date	Open Date	Expires	Extend
159592	MT88	MBELU145899	MBA95K007016	307	95-10-31	99-12-31	04-10-31	
159592	MT88	MBELU145899	MBA93D004010	538315	93-04-30	02-01-15	02-04-30	
159592	MT08	MBELU145099	MBA95K007019	302	95-10-31	99-12-31	04-10-31	
▶ 161422	M507	2520002	MBA86J001030	N/A	86-09-30	09-10-30	08-09-30	
161422	M507	2520002	MBA86H001029	32165898	86-08-31	92-09-18	02-09-30	
161422	M507	2520002	MBA86H001029	954357	86-08-31	92-11-16	02-11-30	

R.S.L. Expiration(s) R.S.L. Specific Asset Removal R.S.L. Maintenance R.S.L. Report

Audio:

To remove a specific asset from the Ready Service Locker, select the asset in the locker and then select the R.S.L. Specific Asset Removal check box at the bottom of the screen. The text in the selected row will highlight red, indicating the item is marked for deletion.

Developer Notes

12/30/2002

DODICs.ppt

46

Locker (Screen 6)

View | Lots

- Select the R.S.L. Maintenance check box at the bottom of the screen to delete assets from the ready service locker.

BuSer	DODIC	Part Number	Expires	Extend
159592	MT88	MBEU145899	04-10-31	
159592	MT88	MBEU145899	02-04-30	
159592	MT88	MBEU145899	04-10-31	
161422	M507	2520002	08-09-30	
161422	M507	2520002	02-09-30	
161422	M507	2520002	02-11-30	

Audio:

To perform maintenance on items in the Ready Service Locker, select the check box by R.S.L. Maintenance at the bottom of the screen.

Developer Notes

12/30/2002

DODICs.ppt

47

Locker (Screen 7)

View | Lots

- Select the type of deletion option to be performed:
 - Remove all Expired Assets
 - Remove 'Delete' Flagged Assets
 - Remove Expired & Flagged Assets
- Click the SUBMIT button to complete the maintenance process.
- The system will prompt you to confirm asset removal.

The screenshot displays the 'VFS - CAD/PAD Installed Assets' application window. A dialog box titled 'R.S.L. Maintenance...' is open, showing three radio button options for asset removal: 'Remove All Expired Assets', 'Remove 'Delete' Flagged Assets', and 'Remove Expired & Flagged Assets'. The 'Remove Expired & Flagged Assets' option is selected. A '- SUBMIT -' button is visible at the bottom of the dialog. In the background, the main application window shows a sidebar with buttons for 'REPLACE', 'BU/SER ASSETS', 'LOCKER', 'LOGBOOK', and 'RETURN'. The main area contains various input fields for asset details and a table of asset data.

Bu/Ser	DODIC	Part Number	Expires	Extend
159592	MT88	MBEU145899	04-10-31	
159592	MT88	MBEU145899	02-04-30	
159592	MT88	MBEU145899	04-10-31	
161422	M507	2520002	08-09-30	
161422	M507	2520002	02-09-30	
161422	M507	2520002	02-11-30	

Audio:

To complete the R.S.L. Maintenance process, choose whether you wish to remove expired assets, delete-flagged assets, or both, and then click the Submit button. The system will prompt you to complete the process.

Developer Notes

12/30/2002


DODICs.ppt

48

Locker (Screen 8)

View | Lots

- Click Yes to remove the assets from the locker.
- Click No to keep the assets in the locker.
- The remaining locker assets will display.
- If no more assets exist in the locker, a message will display stating that no matching assets exist in the ready service locker.



Audio:

Confirm whether to proceed with the Ready Service Locker asset removal. The system will refresh the locker listing remaining assets.

Developer Notes

12/30/2002

DODICs.ppt

49

Locker (Screen 9)

View | Lots

- Select the R.S.L. Report check box to view the contents of the ready service locker.

The screenshot displays a search interface for a Ready Service Locker (R.S.L.). At the top, there are several input fields: MODEX, AIRCRAFT, and a dropdown menu. Below these are fields for SEAT PART NO., SEAT SERIAL, PART NUMBER, SHELF LIFE, and SERV. Further down are fields for NOMENCLATURE, CODE, MFG. DATE, and OPEN. DATE. A table with columns for Lot Number, Serial, Mfg. Date, Open Date, Expires, and Extend is shown. The table contains several rows of data, with one row highlighted in red. At the bottom, there are three checkboxes: Specific Asset Removal, R.S.L. Maintenance, and R.S.L. Report (which is checked).

Lot Number	Serial	Mfg. Date	Open Date	Expires	Extend
MBA95K007016	307	95-10-31	99-12-31	04-10-31	
MBA93D004010	598315	93-04-30	02-01-15	02-04-30	
MBA95K007019	302	95-10-31	99-12-31	04-10-31	
MBA86J001030	N/A	86-09-30	00-10-30	08-09-30	
MBA86H001029	32165898	86-08-31	92-09-18	02-09-30	
MBA86H001029	954357	86-08-31	92-11-16	02-11-30	



Audio:

To view or print the contents of the Ready Service Locker, select the R.S.L. Report check box at the bottom of the screen.

Developer Notes

12/30/2002


DODICs.ppt

50

Locker (Screen 10)

View | Lots

- The Ready Service Locker Report will display.
- Use the navigation buttons to display various report pages.
- Use the zoom buttons to control the size of the report on the screen.
- Click the printer button to print the report.
- Click the X button to close the report.



Audio:

The ready service locker report will display. The report has options to scroll through the pages, display the text larger or smaller, and print.

Developer Notes

12/30/2002

DODICs.ppt

51

Logbook (Screen 1)

View | Lots

- Click the LOGBOOK button to view or print the aircraft logbook.

NOTE: This function is not available while the Installed Assets table displays. Close the Installed Assets table first by clicking the BU/SER ASSETS button.

Installed, ver 1.0.0.2. Connected from: http://cadpadvts

NAVSEA
INTEGRATED
SOFTWARE CENTER
CAD/PAD

VFS - CAD/PAD Installed Assets

Find Edit Add Cancel Delete Save Help X

SQUADRON: VF-101 ORGANIZATION CODE: AC1
BU/SER: 161422 MODEX: AIRCRAFT: F-14B
SEAT NUMBER: SEAT PART NO.:
SEAT DESIG: SEAT SERIAL:
DODIC: PART NUMBER:
LOT: SHELF LIFE: SERV.:
SERIAL NO.: NOMENCLATURE:
LOCATION CODE: MFG. DATE: --
LOCATION: OPEN. DATE: --
MAINTENANCE ORG. CODE: INSTALL DATE: --
EXPIRE DATE: --
EXTEND DATE: --
EXTENDED MONTH(S):

FLEET COMMENTS:
REASON:



Audio:

To view or print the aircraft logbook, click the Logbook button from the menu on the left-hand side of the screen.

Developer Notes

12/30/2002



DODICs.ppt

52

Logbook (Screen 2)

View | Lots

- The Logbook report will display.
- Use the navigation buttons to display various report pages.
- Use the zoom buttons to control the size of the report on the screen.
- Click the printer button to print the report.
- Click the X button to close the report.



Audio:

The report will display on the screen. The report has options to scroll through the pages, display the text larger or smaller, and print.

Developer Notes

12/30/2002


DODICs.ppt

53

Bu/Sers Menu Options

View | Lots

- To access the Bu/Sers screen, click the BU/SERS button from the Main Menu.



Audio:

To display and maintain aircraft bureau number/serial number information, click the Bu/Sers button from the Trace CAD/PAD main menu.

Developer Notes

12/30/2002

DODICs.ppt

54

Add a New Bu/Ser to System (Screen 1 of 7)

View | Lots

- To add a new Bu/Ser to the system, click Add from the menu at the top of the screen.

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

CONFIG
CUSTODY
FREEZE!
S.D.L.M.
REDESIG
RETURN

VFS - CAD/PAD: Bu/Sers Screen

Find Edit **Add** Cancel Delete Save Help

BU/SER: []
AIRCRAFT: [] MODEX: []
SQUADRON: VF-101
LAST UPDATE: []
S.D.L.M. DUE DATE: []

INSPECT. CYCLE: [] days
INSPECT. DATE: []
 INACTIVE: []
 COMMENTS for AIRFRAME
CUSTODY DATE: []

SEAT 1 DESIG.: [] SEAT 3 DESIG.: []
SEAT 1 PART: [] SEAT 3 PART: []
SEAT 1 SERIAL: [] SEAT 3 SERIAL: []
 COMMENTS for SEAT 1 COMMENTS for SEAT 3

SEAT 2 DESIG.: [] SEAT 4 DESIG.: []
SEAT 2 PART: [] SEAT 4 PART: []
SEAT 2 SERIAL: [] SEAT 4 SERIAL: []
 COMMENTS for SEAT 2 COMMENTS for SEAT 4


Audio:

To add a new aircraft to the system, click the Add button.

Add a New Bu/Ser to System (Screen 2 of 7)

View | Lots


- In the text box, type the Bu/Ser Number.



The screenshot shows a web browser window titled "VFS - CAD/PAD: Bu/Sers Screen". The browser address bar shows "http://cadpadvfs". The page has a blue sidebar on the left with the NAVSEA logo and buttons for "CONFIG", "CUSTODY", "FREEZE!", "S.D.L.M.", "REDESIG", and "RETURN". The main content area has a menu bar with "Find", "Edit", "Add", "Cancel", "Delete", "Save", and "Help". Below the menu bar is a form with the following fields:

- BU/SER: [dropdown]
- INSPECT. CYCLE: [text] days
- AIRFRAME: [dropdown]
- DATE: [text]
- SQUADRON: [text]
- ACTIVE: [text]
- LAUNCH: [text]
- MENTS for AIRFRAME: [text]
- S.D.L.M.: [text]
- DATE: [text]
- SEAT: [text]
- SEAT 1 PART: [dropdown]
- SEAT 3 PART: [dropdown]
- SEAT 1 SERIAL: [text]
- SEAT 3 SERIAL: [text]
- COMMENTS for SEAT 1
- COMMENTS for SEAT 3
- SEAT 2 DESIG.: [text]
- SEAT 4 DESIG.: [text]
- SEAT 2 PART: [dropdown]
- SEAT 4 PART: [dropdown]
- SEAT 2 SERIAL: [text]
- SEAT 4 SERIAL: [text]
- COMMENTS for SEAT 2
- COMMENTS for SEAT 4

The Windows taskbar at the bottom shows the Start button, several application icons, and the system tray with the time "10:00 AM".



Audio:

The system will prompt you for a new Bu/Ser number.

Developer Notes

12/30/2002



DODICs.ppt

57

Add a New Bu/Ser to System (Screen 3 of 7)

View | Lots

- In the text box, type the aircraft type.



Audio:

You will be prompted to enter the type of aircraft.

Developer Notes

12/30/2002

DODICs.ppt

58

Add a New Bu/Ser to System (Screen 4 of 7)

View | Lots

- Based on the designated aircraft TMS, the Bu/Ser's configuration will be retrieved.
- Green indicates fields that can be modified for the new Bu/Ser.
- If the aircraft TMS returns a configuration including seats, the seat information must be entered.

Installed, ver 1.0.0.2, Connected from: http://cadpad/vfs

NAVSEA
INNOVATION HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 166220

AIRCRAFT: FA-18C MODEX: [Green]

SQUADRON: VF-101

LAST UPDATE: --

S.D.L.M. DUE DATE: [Green]

INSPECT. CYCLE: days

INSPECT. DATE: [Green]

INACTIVE: --

COMMENTS for AIRFRAME

CUSTODY DATE: --

SEAT 1 DESIG.: PILOT

SEAT 1 PART: [Green]

SEAT 1 SERIAL: [Green]

COMMENTS for SEAT 1

SEAT 2 DESIG.: [White]

SEAT 2 PART: [Green]

SEAT 2 SERIAL: [Green]

COMMENTS for SEAT 2

SEAT 3 DESIG.: [White]

SEAT 3 PART: [Green]

SEAT 3 SERIAL: [Green]

COMMENTS for SEAT 3

SEAT 4 DESIG.: [White]

SEAT 4 PART: [Green]

SEAT 4 SERIAL: [Green]

COMMENTS for SEAT 4

Start Login Pra... C:\ Microsoft... Installe... 10:16 AM

Audio:

Bu/Ser configuration data will display automatically based on the entered aircraft type. Fields that may be modified are highlighted in green. If the aircraft type returns a configuration that includes seats, you must enter the seat serial information.

Developer Notes

12/30/2002

DODICs.ppt

59

Add a New Bu/Ser to System (Screen 5 of 7)

View | Lots

- If more than one part number is available for a seat, click the desired part number from the list.
- Seat serial numbers highlighted in green are mandatory entries.

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 166220
AIRCRAFT: FA-18C MODEX:
SQUADRON: VF-101
LAST UPDATE: - -
S.D.L.M. DUE DATE: - -

INSPECT. CYCLE: days
INSPECT. DATE: - -
 INACTIVE: - -
 COMMENTS for AIRFRAME
CUSTODY DATE: - -

SEAT 1 DESIG.: PILOT
SEAT 1 PART:
SEAT 1 SERIAL: SJU-5/A
 COMMENTS for SEAT 1

SEAT 2 DESIG.:
SEAT 2 PART:
SEAT 2 SERIAL:
 COMMENTS for SEAT 2

SEAT 3 DESIG.:
SEAT 3 PART:
SEAT 3 SERIAL:
 COMMENTS for SEAT 3

SEAT 4 DESIG.:
SEAT 4 PART:
SEAT 4 SERIAL:
 COMMENTS for SEAT 4

Audio:

More than one part number may exist for a seat. If so, a drop-down arrow is available in the seat part number field. Seat serial numbers are mandatory entries.

Developer Notes

12/30/2002

DODICs.ppt

60

Add a New Bu/Ser to System (Screen 6 of 7)

View | Lots

- Comments can be added or viewed for the airframe and seats by selecting the check box next to the appropriate comment type. A comment field will display at the bottom of the screen.
- The label for the selected comment field will change to white.

Installed, ver 1.0.0.2, connected from: http://cadpadvfs

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

Find Edit Add Cancel Delete Save Help

BU/SER: 166220 INSPECT. CYCLE: days
AIRCRAFT: FA-18C MODEX: INSPECT. DATE: INACTIVE: COMMENTS for AIRFRAME
SQUADRON: VF-101 CUSTODY DATE:
LAST UPDATE: S.D.L.M. DUE DATE:
SEAT 1 DESIG.: PILOT SEAT 3 DESIG.:
SEAT 1 PART: SJU-5/A SEAT 3 PART:
SEAT 1 SERIAL: 9674 SEAT 3 SERIAL:
COMMENTS for SEAT 1 COMMENTS for SEAT 3
SEAT 2 DESIG.: SEAT 4 DESIG.:
SEAT 2 PART: SEAT 4 PART:
SEAT 2 SERIAL: SEAT 4 SERIAL:
COMMENTS for SEAT 2 COMMENTS for SEAT 4

AIRFRAME COMMENTS:

Start Login Fra... C:\ Microsoft... Install... 10:10 AM



Audio:

Comments for the airframe and seats can be entered and viewed at the bottom of the screen when you select the check box next to the comment type.

Developer Notes

12/30/2002

DODICs.ppt

61

Add a New Bu/Ser to System (Screen 7 of 7)

View | Lots

- To save the new Bu/Ser in the system, click Save from the menu at the top of the screen.
- To cancel the addition, click Cancel.

NAVSEA
NORTH HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add **Cancel** Delete Save Help

BU/SER: 166220 INSPECT. CYCLE: days
AIRCRAFT: FA-18C MODEX: INSPECT. DATE: INACTIVE: COMMENTS for AIRFRAME
SQUADRON: VF-101
LAST UPDATE: S.D.L.M. DUE DATE: CUSTODY DATE: COMMENTS for SEAT 1 COMMENTS for SEAT 3
SEAT 1 DESIG.: PILOT SEAT 3 DESIG.: SEAT 3 SERIAL: COMMENTS for SEAT 2
SEAT 1 PART: SJJ-5/A SEAT 4 DESIG.: SEAT 4 PART: SEAT 4 SERIAL: COMMENTS for SEAT 4
SEAT 1 SERIAL: 9674
SEAT 2 DESIG.: SEAT 2 PART: SEAT 2 SERIAL: COMMENTS for SEAT 2
AIRFRAME COMMENTS: AIRFRAME COMMENTS



Audio:

Once you have added all necessary data, click the Save button to save the information, or click the Cancel button to cancel your changes.

Developer Notes

12/30/2002

DODICs.ppt

62

Find/View a Bu/Ser (Screen 1 of 4)

View | Lots

- Based on the user logon ID, either the user's squadron or activity will display.
- When a user selects the Bu/Ser, the physical custodian of the Bu/Ser will display in the SQUADRON field.

Installed, ver 1.0.0.2, Connected from http://cadpadvfs

NAVSEA
INMAN HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: [] AIRCRAFT: [] MODEX: [] INSPECT. CYCLE: [] days
INSPECT. DATE: []
SQUADRON: VF-101 INACTIVE: []
LAST UPDATE: [] COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: [] CUSTODY DATE: []

SEAT 1 DESIG.: [] SEAT 3 DESIG.: []
SEAT 1 PART: [] SEAT 3 PART: []
SEAT 1 SERIAL: [] SEAT 3 SERIAL: []
 COMMENTS for SEAT 1 COMMENTS for SEAT 3

SEAT 2 DESIG.: [] SEAT 4 DESIG.: []
SEAT 2 PART: [] SEAT 4 PART: []
SEAT 2 SERIAL: [] SEAT 4 SERIAL: []
 COMMENTS for SEAT 2 COMMENTS for SEAT 4

Start | Login Fra... | C:\ | Microsoft... | Install... | 10:24 AM



Audio:

The user's squadron or activity will display on initial entry. Once a Bu/Ser is selected, the physical custodian of the Bu/Ser will display in the Squadron field.

Find/View a Bu/Ser (Screen 2 of 4)

View | Lots

- You may display any Bu/Ser for which you have access.
- Click the desired Bu/Ser from the Bu/Ser list, or type a specific Bu/Ser number in the box.

NOTE: This version of Trace does not support searches by **modex**.

NAVSEA
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: [dropdown menu]
AIRCRAFT: 159592
SQUADRON: 161274
LAST UPDAT: 161279
S.D.L.M. DUR: 161416
SEAT 1 DESIG: 161422
SEAT 1 PART: 161432
SEAT 1 SERIAL: 161440
SEAT 2 DESIG: [text field]
SEAT 2 PART: [text field]
SEAT 2 SERIAL: [text field]
SEAT 3 DESIG: [text field]
SEAT 3 PART: [text field]
SEAT 3 SERIAL: [text field]
SEAT 4 DESIG: [text field]
SEAT 4 PART: [text field]
SEAT 4 SERIAL: [text field]

MODEX: [text field]
INSPECT. CYCLE: [text field] days
INSPECT. DATE: [text field]
 INACTIVE: [text field]
 COMMENTS for AIRFRAME
CUSTODY DATE: [text field]
 COMMENTS for SEAT 1
 COMMENTS for SEAT 2
 COMMENTS for SEAT 3
 COMMENTS for SEAT 4

Start | [icons] | Login Pra... | C:\ | Microsoft... | Install... | [system tray] | 10:26 AM



Audio:

Click the drop-down arrow in the Bu/Ser field to display a list of existing data. You can click an item from the list or manually type the information.

Developer Notes

12/30/2002

DODICs.ppt

64

Find/View a Bu/Ser (Screen 3 of 4)

View | Lots

- The data for the selected Bu/Ser will display.
- At this point, you can [edit the information](#), [display configuration data](#), [transfer custody](#), [freeze the data](#), or [strip assets for SDLM](#).

Installed, ver 1.00.2, Connected from: https://cadpadvfs

NAVSEA
INDIAN HEAD
Navy Warfare Center Division
CAD/PAD

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 166220 INSPECT. CYCLE: 448 days
AIRCRAFT: FA-18C MODEX: 100 INSPECT. DATE: --
SQUADRON: VF-101 INACTIVE: --
LAST UPDATE: 02-08-13 COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: -- CUSTODY DATE: 02-08-13

SEAT 1 DESIG.: PILOT SEAT 3 DESIG.:
SEAT 1 PART: SJU-5/A SEAT 3 PART:
SEAT 1 SERIAL: 9674 SEAT 3 SERIAL:
 COMMENTS for SEAT 1 COMMENTS for SEAT 3

SEAT 2 DESIG.: SEAT 4 DESIG.:
SEAT 2 PART: SEAT 4 PART:
SEAT 2 SERIAL: SEAT 4 SERIAL:
 COMMENTS for SEAT 2 COMMENTS for SEAT 4

Start Login Fra... c:\ Microsoft... Install... 10:00 AM



Audio:

Once Bu/Ser data is displayed on your screen, you can make changes to the data, transfer custody, freeze the data, or strip the assets for SDLM.

Developer Notes

12/30/2002

DODICs.ppt

65

Find/View a Bu/Ser (Screen 4 of 4)

View | Lots

- If the airframe or seats have an associated comment, the field will be underlined.
- To view the comment, select the check box near the desired comment type.
- The comment will display at the bottom of the screen.
- Clear the check box to remove the displayed comment. This will not delete the comment.

NAVSEA
Surface Warfare Center Division
CAD/PAD

CONFIG
CUSTODY
FREEZE!
S.D.L.M.
REDESIG
RETURN

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 166220 INSPECT. CYCLE: 448 days
AIRCRAFT: FA-18C MODEX: 100 INSPECT. DATE: --
SQUADRON: VF-101 INACTIVE: --
LAST UPDATE: 02-08-13 COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: -- CUSTODY DATE: 02-08-13

SEAT 1 DESIG.: PILOT SEAT 3 DESIG.:
SEAT 1 PART: SJU-5/A SEAT 3 PART:
SEAT 1 SERIAL: 9674 SEAT 3 SERIAL:
 COMMENTS for SEAT 1 COMMENTS for SEAT 3

SEAT 2 DESIG.: SEAT 4 DESIG.:
SEAT 2 PART: SEAT 4 PART:
SEAT 2 SERIAL: SEAT 4 SERIAL:
 COMMENTS for SEAT 2 COMMENTS for SEAT 4

AIRFRAME COMMENTS: AIRFRAME COMMENTS



Audio:

To view associated airframe or seat comments, select the check box next to the appropriate comment type. The comments will display at the bottom of the screen.

Developer Notes

12/30/2002

DODICs.ppt

66

Edit Bu/Ser Information (Screen 1 of 5)

View | Lots

- Find the Bu/Ser to be edited.
- Click Edit from the menu at the top of the screen.
- Green indicates fields that can be modified for the Bu/Ser.

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 166220 INSPECT. CYCLE: 448 days
AIRCRAFT: FA-18C MODEX: 100 INSPECT. DATE: --
SQUADRON: VF-101 INACTIVE: --
LAST UPDATE: 02-08-13 COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: -- CUSTODY DATE: 02-08-13

SEAT 1 DESIG.: PILOT SEAT 3 DESIG.:
SEAT 1 PART: SJJ-5/A SEAT 3 PART:
SEAT 1 SERIAL: 9674 SEAT 3 SERIAL:
 COMMENTS for SEAT 1 COMMENTS for SEAT 3

SEAT 2 DESIG.: SEAT 4 DESIG.:
SEAT 2 PART: SEAT 4 PART:
SEAT 2 SERIAL: SEAT 4 SERIAL:
 COMMENTS for SEAT 2 COMMENTS for SEAT 4

Audio:

Find the Bu/Ser to be edited and then click the Edit button from the menu. Fields that may be modified are highlighted in green.

Developer Notes

12/30/2002

DODICs.ppt

67

Edit Bu/Ser Information (Screen 2 of 5)

View | Lots

- Make necessary changes to green highlighted fields only.
- Enter dates using the YYMMDD format. Dashes will be added automatically.
- Data is capitalized automatically.

NAVSEA
INTEGRATED
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD: Bu/Sers Screen


Find Edit Add Cancel Delete Save Help

BU/SER: 166220 INSPECT. CYCLE: 448 days
AIRCRAFT: FA-18C MODEX: 100 INSPECT. DATE: - -
SQUADRON: VF-101 INACTIVE: - -
LAST UPDATE: 02-08-13 COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: - - CUSTODY DATE: 02-08-13

SEAT 1 DESIG: PILOT SEAT 3 DESIG.:
SEAT 1 PART: SJU-5/A SEAT 3 PART:
SEAT 1 SERIAL: 9674 SEAT 3 SERIAL:
 COMMENTS for SEAT 1 COMMENTS for SEAT 3

SEAT 2 DESIG.: SEAT 4 DESIG.:
SEAT 2 PART: SEAT 4 PART:
SEAT 2 SERIAL: SEAT 4 SERIAL:
 COMMENTS for SEAT 2 COMMENTS for SEAT 4

Start Login Fra... CA Microsoft... Install... 10:24 AM



Audio:

Modify green fields only. When typing dates, type them in the Year-Year Month-Month Day-Day format.

Developer Notes

12/30/2002

DODICs.ppt

68

Edit Bu/Ser Information (Screen 3 of 5)

View | Lots

- If the airframe or seats have an associated comment, the field will be underlined.
- To add or edit a comment, select the check box near the desired comment type.
- The comment will display at the bottom of the screen. You can make changes to the comment or add a new comment.
- Clear the check box to remove the displayed comment. This will not delete the comment.

The screenshot shows a web-based interface for editing aircraft and seat information. The title bar indicates it is installed, version 1.0.0.2, and connected from http://cadpadvfs. The main window is titled "VFS - CAD/PAD: Bu/Sers Screen". On the left, there is a vertical menu with buttons for CONFIG, CUSTODY, FREEZE!, S.D.L.M., REDESIG, and RETURN. The main area contains several input fields and checkboxes. The aircraft information includes BU/SER: 166220, AIRCRAFT: FA-18C, MODEX: 100, SQUADRON: VF-101, LAST UPDATE: 02-08-13, and S.D.L.M. DUE DATE: --. The seat information includes SEAT 1 DESIG.: PILOT, SEAT 1 PART: SJU-5/A, SEAT 1 SERIAL: 9674, SEAT 2 DESIG.: , SEAT 2 PART: , SEAT 2 SERIAL: , SEAT 3 DESIG.: , SEAT 3 PART: , SEAT 3 SERIAL: , SEAT 4 DESIG.: , SEAT 4 PART: , SEAT 4 SERIAL: . There are checkboxes for COMMENTS for SEAT 1, SEAT 2, SEAT 3, and SEAT 4. The AIRFRAME COMMENTS field is currently empty. The bottom of the screen shows a Windows taskbar with various icons and the time 10:27 AM.



Audio:

To add or edit a comment, select the check box next to the appropriate comment type. The comment field will display at the bottom of the screen.

Developer Notes

12/30/2002

DODICs.ppt

69

Edit Bu/Ser Information (Screen 4 of 5)

View | Lots

- Each seat could have multiple associated part numbers for aircraft TMS.

Note: The LAST UPDATE field will be updated automatically when a change is made on the Installed Asset Screen. This field is not updated when the Bu/Ser data is changed - only when an installed asset is changed.

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 166220
AIRCRAFT: FA-18C MODEX: [redacted]
SQUADRON: VF-101
LAST UPDATE: --
S.D.L.M. DUE DATE: --

INSPECT. CYCLE: [redacted] days
INSPECT. DATE: --
 INACTIVE: --
 COMMENTS for AIRFRAME
CUSTODY DATE: --

SEAT 1 DESIG.: PILOT
SEAT 1 PART: [redacted]
SEAT 1 SERIAL: SJU-5/A
 COMMENTS for SEAT 1

SEAT 2 DESIG.: [redacted]
SEAT 2 PART: [redacted]
SEAT 2 SERIAL: [redacted]
 COMMENTS for SEAT 2

SEAT 3 DESIG.: [redacted]
SEAT 3 PART: [redacted]
SEAT 3 SERIAL: [redacted]
 COMMENTS for SEAT 3

SEAT 4 DESIG.: [redacted]
SEAT 4 PART: [redacted]
SEAT 4 SERIAL: [redacted]
 COMMENTS for SEAT 4

CONFIG
CUSTODY
FREEZE!
S.D.L.M.
REDESIG
RETURN

Start Login Fra... C:\ Microsoft... Install... 10:16 AM



Audio:

Seats may have more than one part number associated with **them**.

When a change is made to an installed asset on the Installed Asset Screen, the Last Update field will automatically be updated with the current date. However, if the Bu/Sers data is changed, the Last Update field does not update with the current date.

Developer Notes

12/30/2002

DODICs.ppt

70

Edit Bu/Ser Information (Screen 5 of 5)

View | Lots

- To save the Bu/Ser changes, click Save from the menu at the top of the screen.
- To cancel the changes, click Cancel.

NOTE: You must either save or cancel changes before you can view another Bu/Ser.

Installed, ver 1.00.2, Connected from: http://cadpadvfs


VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 166220 INSPECT. CYCLE: 448 days
AIRCRAFT: FA-18C MODEX: 100 INSPECT. DATE: -- --
SQUADRON: VF-101 INACTIVE: -- --
LAST UPDATE: 02-08-13 COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: -- -- CUSTODY DATE: 02-08-13

SEAT 1 DESIG.: PILOT SEAT 3 DESIG.:
SEAT 1 PART: SJU-5/A SEAT 3 PART:
SEAT 1 SERIAL: 9673 SEAT 3 SERIAL:
 COMMENTS for SEAT 1 COMMENTS for SEAT 3

SEAT 2 DESIG.: SEAT 4 DESIG.:
SEAT 2 PART: SEAT 4 PART:
SEAT 2 SERIAL: SEAT 4 SERIAL:
 COMMENTS for SEAT 2 COMMENTS for SEAT 4



Audio:

Once you have made all necessary changes, click the Save button to save the information, or click the Cancel button to cancel your changes

Developer Notes

12/30/2002

DODICs.ppt

71

Delete a Bu/Ser from System

View | Lots

- To delete a Bu/Ser, you must contact Indian Head personnel.

Commercial: (301)744-2233

DSN: 354-2233

Fax: (301)744-6699/4881

Email: cadpadtrace@ih.navy.mil



Audio:

Only approved Indian Head personnel have the ability to delete a Bu/Ser from the system.

Developer Notes

12/30/2002

DODICs.ppt

72

Configuration Report (Screen 1 of 3)

View | Lots

- To display a configuration report for the selected Bu/Ser, [find the Bu/Ser](#) to be reported.
- Click the CONFIG button on the left-hand side of the screen.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

CONFIG
CUSTODY
FREEZE!
S.D.L.M.
REDESIG
RETURN

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 166220 INSPECT. CYCLE: 448 days
AIRCRAFT: FA-18C MODEX: 100 INSPECT. DATE: --
SQUADRON: VF-101 INTERACTIVE: --
LAST UPDATE: 02-08-13 COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: -- CUSTODY DATE: 02-08-13

SEAT 1 DESIG.: PILOT SEAT 3 DESIG.:
SEAT 1 PART: SJU-5/A SEAT 3 PART:
SEAT 1 SERIAL: 9673 SEAT 3 SERIAL:
 COMMENTS for SEAT 1 COMMENTS for SEAT 3

SEAT 2 DESIG.: SEAT 4 DESIG.:
SEAT 2 PART: SEAT 4 PART:
SEAT 2 SERIAL: SEAT 4 SERIAL:
 COMMENTS for SEAT 2 COMMENTS for SEAT 4

Start Login Fra... CA Microsoft... Installe... 10:45 AM

Audio:

To view the configuration report, find the desired Bu/Ser and then click the Config button.

Developer Notes

12/30/2002

DODICs.ppt

73

Configuration Report (Screen 2 of 3)

View | Lots

- The configuration report of assets that are located on the selected Bu/Ser will display.

NOTE: It may take a while to load if the aircraft has a large configuration.

LOC. CODE	LOCATION	DODIC	PRIMARY PART NUMBER	SEAT NO.
P01	SEAT	CW018	MBEU1142900	1
P02	LH SEAT	MR50	Z09A0125	1
P03	RH SEAT	MR50	Z09A0125	1
P04	CATAPULT	MT07	MBEU142220	1
P04	CATAPULT	WB15	MBEU148144.1	1
P05	LH SEAT	MT13	MBEU148255	1
P06	RH SEAT	MT13	MBEU148255	1
P07	PARACHUTE EXTRACTOR	MT20	MBEU148100	1
P08	AFT SEAT BUCKET	MT21	MBEU142802	1
P09	RH SEAT	MT00	MBEU1140000	1



Audio:

Depending on the size of the configuration, it may take several minutes to display the configuration data.

Developer Notes

12/30/2002

DODICs.ppt


74

Configuration Report (Screen 3 of 3)

View | Lots

- Use the navigation buttons to display various report pages.
- Use the zoom buttons to control the size of the report on the screen.
- Click the printer button to print the report.
- Click the **X** button to close the report.

LOC. CODE	LOCATION	DODIC	PRIMARY PART NUMBER	SEAT NO.
P01	SEAT	CM010	MBEU1140900	1
P02	LH SEAT	MR50	Z09A0125	1
P03	RH SEAT	MR50	Z09A0125	1
P04	CATAPULT	MT07	MBEU142220	1
P04	CATAPULT	WB15	MBEU148144.1	1
P05	LH SEAT	MT13	MBEU148255	1
P06	RH SEAT	MT13	MBEU148255	1
P07	PARACHUTE EXTRACTOR	MT20	MBEU148100	1
P08	AFT SEAT BUCKET	MT21	MBEU142802	1
P09	RH SEAT	MT00	MBEU1140900	1



Audio:

The report has options to scroll through the pages, display the text larger or smaller, and print.

Developer Notes

12/30/2002

DODICs.ppt

75

View or Transfer Custody (Screen 1 of 8)

View | Lots

- **Find the Bu/Ser** to be transferred or viewed.
- Click the **CUSTODY** button on the left-hand side of the screen to display custody information for the selected Bu/Ser.

Note: The custody option is not available while a Bu/Ser is being edited or added.

Installed, ver 1.0.0.2, Connected from http://cadpadvfs

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 166220 INSPECT. CYCLE: 448 days
AIRCRAFT: FA-18C MODEX: 100 INSPECT. DATE: --
SQUADRON: VF-101 INACTIVE: --
LAST UPDATE: 02-08-13 COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: -- CUSTODY DATE: 02-08-13

SEAT 1 DESIG.: PILOT SEAT 3 DESIG.:
SEAT 1 PART: S.JU-5/A SEAT 3 PART:
SEAT 1 SERIAL: 9673 SEAT 3 SERIAL:
 COMMENTS for SEAT 1 COMMENTS for SEAT 3

SEAT 2 DESIG.: SEAT 4 DESIG.:
SEAT 2 PART: SEAT 4 PART:
SEAT 2 SERIAL: SEAT 4 SERIAL:
 COMMENTS for SEAT 2 COMMENTS for SEAT 4

Start Login Fra... CA Microsoft... Installe... 10:50 AM



Audio:

To view or transfer custody of a Bu/Ser, find the Bu/Ser and then click the Custody button.

Developer Notes

12/30/2002

DODICs.ppt

76

View or Transfer Custody (Screen 2 of 8)

View | Lots

- Aircraft custody data will display at the bottom of the screen.
- Squadrons holding physical and reporting custody will display.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

CONFIG
CUSTODY
FREEZE!
S.D.L.M.
REDESIG
RETURN

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 166220 INSPECT. CYCLE: 448 days
AIRCRAFT: FA-18C MODEX: 100 INSPECT. DATE: --
SQUADRON: VF-101 INTERACTIVE: --
LAST UPDATE: 02-08-13 COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: -- CUSTODY DATE: 02-08-13

SEAT 1 DESIG: PILOT SEAT 3 DESIG: --
SEAT 1 PART: SJU-5/A SEAT 3 PART: --
SEAT 1 SERIAL: 9673 SEAT 3 SERIAL: --
 COMMENTS for SEAT 1 COMMENTS for SEAT 3

AIRCRAFT CUSTODY

TRANSFER AIRCRAFT BY: --

PHYSICAL: VF-101 REPORTING: VF-101 TRANSFER TO: -- A.T.O. NUMBER: --
A.T.O. MESSAGE: --

TRANSFER BU/SER UPDATE INFORMATION CANCEL

Start Login Fra... C:\Trace... Microsoft... Install... 10:55 AM

Audio:

Squadrons that currently hold physical and reporting custody of the Bu/Ser will display.

Developer Notes

12/30/2002

DODICs.ppt

77

View or Transfer Custody (Screen 3 of 8)

View | Lots

- To update transfer information, click the **UPDATE INFORMATION** button in the **AIRCRAFT CUSTODY** area.

The screenshot displays the 'VFS - CAD/PAD: Bu/Sers Screen' interface. On the left is a blue sidebar with buttons: CONFIG, CUSTODY (highlighted), FREEZE!, S.D.L.M., REDESIG, and RETURN. The main area contains a form with the following fields and values:

- BU/SER: 166220
- AIRCRAFT: FA-18C
- MODEX: 100
- SQUADRON: VF-101
- LAST UPDATE: 02-08-13
- S.D.L.M. DUE DATE: --
- INSPECT. CYCLE: 448 days
- INSPECT. DATE: --
- INACTIVE: --
- COMMENTS for AIRFRAME
- CUSTODY DATE: 02-08-13
- SEAT 1 DESIG: PILOT
- SEAT 1 PART: SJU-5/A
- SEAT 1 SERIAL: 9673
- SEAT 3 DESIG: (empty)
- SEAT 3 PART: (empty)
- SEAT 3 SERIAL: (empty)
- COMMENTS for SEAT 1 (empty)
- COMMENTS for SEAT 3 (empty)
- AIRCRAFT CUSTODY (pop-up window):
 - TRANSFER AIRCRAFT BY: --
 - PHYSICAL: VF-101
 - REPORTING: VF-101
 - TRANSFER TO: (empty)
 - A.T.O. NUMBER: (empty)
 - A.T.O. MESSAGE: (empty)
 - Buttons: TRANSFER BU/SER, UPDATE INFORMATION (highlighted), CANCEL



Audio:

To update transfer information of a Bu/Ser, select the Update Information button located within the Aircraft Custody area.

Developer Notes

12/30/2002

DODICs.ppt

78

View or Transfer Custody (Screen 4 of 8)

View | Lots

- Modify the fields highlighted in green. These are mandatory entries.
- The label for the UPDATE INFORMATION button changes to SAVE NEW DATA.
- **NOTE:** The TRANSFER AIRCRAFT BY date must be greater than or equal to the current date.

NAVSEA
INFORM HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help X

BU/SER: 166220 INSPECT. CYCLE: 448 days
AIRCRAFT: FA-18C MODEX: 100 INSPECT. DATE: --
SQUADRON: VF-101 INACTIVE: --
LAST UPDATE: 02-08-13 COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: -- CUSTODY DATE: 02-08-13

SEAT 1 DESIG.: PILOT SEAT 3 DESIG.:
SEAT 1 PART: SJU-5/A SEAT 3 PART:
SEAT 1 SERIAL: 9673 SEAT 3 SERIAL:

COMMENTS for SEAT 1 COMMENTS for SEAT 3


AIRCRAFT CUSTODY

TRANSFER AIRCRAFT BY: --

PHYSICAL: VF-101 REPORTING: VF-101 TRANSFER TO: A.T.O. NUMBER:
A.T.O. MESSAGE:

TRANSFER BU/SER SAVE NEW DATA CANCEL

Start Login Fra... C:\Trace... Microsoft... Install... 10:56 AM



Audio:

Editable fields are highlighted in green indicating mandatory entries.

Developer Notes

12/30/2002

DODICs.ppt

79

View or Transfer Custody (Screen 5 of 8)

View | Lots

- Click the SAVE NEW DATA button in the AIRCRAFT CUSTODY area to update the information or the CANCEL button to discard changes.
- After you have saved new data, the button label changes back to UPDATE INFORMATION.

NOTE: Once the data is saved, the receiving squadron will have read-only access to the Bu/Ser's data.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 166220 INSPECT. CYCLE: 448 days
AIRCRAFT: FA-18C MODEX: 100 INSPECT. DATE: --
SQUADRON: VF-101 INACTIVE: --
LAST UPDATE: 02-08-13 COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: -- CUSTODY DATE: 02-08-13

SEAT 1 DESIG: PILOT SEAT 3 DESIG: --
SEAT 1 PART: SJU-5/A SEAT 3 PART: --
SEAT 1 SERIAL: 9673 SEAT 3 SERIAL: --
 COMMENTS for SEAT 1 COMMENTS for SEAT 3

AIRCRAFT CUSTODY

TRANSFER AIRCRAFT BY: 02-08-13

PHYSICAL: VF-101 REPORTING: VF-101 TRANSFER TO: VFA-106 A.T.O. NUMBER: LANT-022

A.T.O. MESSAGE: GNAL 0691400Z MAR 01

TRANSFER BU/SER SAVE NEW DATA CANCEL

Start Login Fra... C:\Trace... Microsoft... Install... 11:00 AM



Audio:

Click the Save New Data button to proceed with the transfer. The squadron receiving the Bu/Ser will have read-only access as soon as the Save New Data button is clicked.

Developer Notes

12/30/2002

DODICs.ppt

80

View or Transfer Custody (Screen 6 of 8)

View | Lots

- After saving the transfer information, click the TRANSFER BU/SER button from the AIRCRAFT CUSTODY area.

The screenshot displays the 'VFS - CAD/PAD: Bu/Sers Screen' interface. On the left, a vertical menu contains buttons for 'CONFIG', 'CUSTODY', 'FREEZE!', 'S.D.L.M.', 'REDESIG', and 'RETURN'. The main window is a data entry form with the following fields and values:

- BU/SER: 166220
- AIRCRAFT: FA-18C
- MODEX: 100
- SQUADRON: VF-101
- LAST UPDATE: 02-08-13
- S.D.L.M. DUE DATE: - -
- INSPECT. CYCLE: 448 days
- INSPECT. DATE: - -
- INACTIVE: - -
- COMMENTS for AIRFRAME
- SEAT 1 DESIG: PILOT
- SEAT 1 PART: SJU-5/A
- SEAT 1 SERIAL: 9673
- SEAT 3 DESIG: [empty]
- SEAT 3 PART: [empty]
- SEAT 3 SERIAL: [empty]
- COMMENTS for SEAT 1
- COMMENTS for SEAT 3
- TRANSFER AIRCRAFT BY: 02-08-13
- PHYSICAL: VF-101
- REPORTING: VF-101
- TRANSFER TO: VFA-106
- A.T.O. NUMBER: LANT-022
- A.T.O. MESSAGE: CNAL 0691400Z MAR 01

At the bottom of the form, there are three buttons: 'TRANSFER BU/SER', 'UPDATE INFORMATION', and 'CANCEL'. The 'TRANSFER BU/SER' button is highlighted with a mouse cursor.



Audio:

When you have completed entering the new data, click the Transfer Bu/Ser button located within the Aircraft Custody area.

Developer Notes

12/30/2002

DODICs.ppt

81

View or Transfer Custody (Screen 7 of 8)

View | Lots

- The system will prompt you on whether or not reporting custody is being transferred.
- If you click yes, both the physical and reporting custody are transferred and the transferring squadron no longer has access to the Bu/Ser's data.

Installed, ver 1.0012, Connected from: http://cadpad/vfs

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 166220 INSPECT. CYCLE: 448 days
AIRCRAFT: FA-18C MODEX: 100 INSPECT. DATE: --
SQUADRON: VF-101 INACTIVE: --
LAST UPDATE: 02-08-13 COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: -- CUSTODY DATE: 02-08-13

SEAT 1 DESIG: P T3 DESIG:
SEAT 1 PART: 1 Will squadron 'YFA-106' have reporting custody? T3 PART:
SEAT 1 SERIAL: 9 T3 SERIAL:
 COMMENTS for AIRFRAME COMMENTS for SEAT 3

AIRCRAFT CUSTODY

TRANSFER AIRCRAFT BY: 02-08-13

PHYSICAL:	REPORTING:	TRANSFER TO:	A.T.O. NUMBER:
VF-101	VF-101	VFA-106	LANT-022

A.T.O. MESSAGE: CNAL 0691400Z MAR 01

TRANSFER BU/SER UPDATE INFORMATION CANCEL



Audio:

You are then prompted whether or not to transfer reporting custody. If you click yes, both physical and reporting custody are transferred. The transferring squadron will no longer have access to the Bu/Ser's data.

Developer Notes

12/30/2002

DODICs.ppt

82

View or Transfer Custody (Screen 8 of 8)

View | Lots

- If you click No, you are prompted whether or not to transfer physical custody.
- When only physical custody is transferred, the transferring squadron has read-only access to the Bu/Ser's data and the squadron gaining physical custody has write access to the data.

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 166220 INSPECT. CYCLE: 448 days

AIRCRAFT: FA-18C MODEX: 100 INSPECT. DATE: --

SQUADRON: VFA-106 INACTIVE: --

LAST UPDATE: 02-08-13 COMMENTS for AIRFRAME

S.D.L.M. DUE DATE: -- CUSTODY DATE: 02-08-13

SEAT 1 DESIG: PILOT SEAT 3 DESIG: --

SEAT 1 PART: SJU-5/A SEAT 3 PART: --

SEAT 1 SERIAL: 9673 SEAT 3 SERIAL: --

COMMENTS for SEAT 1 COMMENTS for SEAT 3

AIRCRAFT CUSTODY

TRANSFER AIRCRAFT BY: --

PHYSICAL: VFA-106 REPORTING: VF-101 TRANSFER TO: -- A.T.O. NUMBER: --

A.T.O. MESSAGE: --

TRANSFER BU/SER UPDATE INFORMATION CANCEL



Audio:

If you click no, you will be prompted whether or not you want to transfer physical custody. If you opt to transfer only physical custody, the transferring squadron will only have read access to the Bu/Ser's data. The squadron containing physical custody will have write access.

Freeze Data for an Investigation (Screen 1 of 4)

View | Lots

- To freeze a Bu/Ser's data for investigation, [find the Bu/Ser](#).
- Click the FREEZE! button on the left-hand side of the screen.

NAVSEA
INFORMAL HEAD
Surface Warfare Center Division
CAD/PAD

CONFIG
CUSTODY
FREEZE!
S.D.L.M.
REDESIG
RETURN

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 161274 INSPECT. CYCLE: 224 days
AIRCRAFT: F-14A MODEX: 131 INSPECT. DATE: 02-09-16
SQUADRON: VF-101 InACTIVE: - -
LAST UPDATE: 02-05-22 COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: - - CUSTODY DATE: 02-02-08

SEAT 1 DESIG.: PILOT SEAT 3 DESIG.:
SEAT 1 PART: MK-GRU-7A-1 SEAT 3 PART:
SEAT 1 SERIAL: 973 SEAT 3 SERIAL:
 COMMENTS for SEAT 1 COMMENTS for SEAT 3

SEAT 2 DESIG.: NFO SEAT 4 DESIG.:
SEAT 2 PART: MK-GRU-7A-2 SEAT 4 PART:
SEAT 2 SERIAL: 972 SEAT 4 SERIAL:
 COMMENTS for SEAT 2 COMMENTS for SEAT 4

Audio:

To freeze a Bu/Ser's data for investigation, find the Bu/Ser to be frozen and then click the Freeze button located on the left-hand side of the screen.

Developer Notes

12/30/2002


DODICs.ppt

84

Freeze Data for an Investigation (Screen 2 of 4)

View | Lots

- A warning will display stating that information will be locked and inaccessible.
- You must acknowledge this warning.



Audio:

The system will display a warning indicating that the Bu/Ser's data will be locked and inaccessible.

Developer Notes

12/30/2002


DODICs.ppt

85

Freeze Data for an Investigation (Screen 3 of 4)

View | Lots

- A second warning will prompt you to confirm that you wish to freeze the data.
- Click Yes to continue with the freeze or No to abort the freeze.



Audio:

The system will prompt you to confirm freezing the Bu/Ser's data.

Developer Notes

12/30/2002

DODICs.ppt

86

Freeze Data for an Investigation (Screen 4 of 4)

View | Lots

- Indian Head, Safety Center, Wing, and TYCOMs are the only users who have the ability to unfreeze data.
- When the data is frozen, all fields are highlighted in blue, indicating data may only be viewed.

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

CONFIG
CUSTODY
UNFREEZE!
S.D.L.M.
REDESIG
RETURN

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

BU/SER: 161274
AIRCRAFT: F-14A MODEX: 131
SQUADRON: VF-101
LAST UPDATE: 02-05-22
S.D.L.M. DUE DATE: - -

INSPECT. CYCLE: 224 days
INSPECT. DATE: 02-09-16
 INACTIVE: - -
 COMMENTS for AIRFRAME
CUSTODY DATE: 02-02-08

SEAT 1 DESIG: PILOT
SEAT 1 PART: MK-GRU-7A-1
SEAT 1 SERIAL: 973
 COMMENTS for SEAT 1

SEAT 2 DESIG: NFO
SEAT 2 PART: MK-GRU-7A-2
SEAT 2 SERIAL: 972
 COMMENTS for SEAT 2

SEAT 3 DESIG:
SEAT 3 PART:
SEAT 3 SERIAL:
 COMMENTS for SEAT 3

SEAT 4 DESIG:
SEAT 4 PART:
SEAT 4 SERIAL:
 COMMENTS for SEAT 4

Start Login Fra... C:\Trace... Microsoft... Install... 11:20 AM



Audio:

Frozen data may only be unfrozen by approved personnel. After data has been frozen, it is read-only.

Strip the Bu/Ser Logbook for S.D.L.M (Screen 1 of 5)

View | Lots

- The SDLM function may only be used by Depot activities to strip a Bu/Ser of assets.
- **Find the Bu/Ser** and then click the S.D.L.M. button located on the left-hand side of the screen.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

VFS - CAD/PAD: Bu/Sers Screen

Find Edit Add Cancel Delete Save Help

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

CONFIG
CUSTODY
FREEZE!
S.D.L.M.
REDESIG
RETURN

BU/SER: 161118 INSPECT. CYCLE: 224 days
AIRCRAFT: EA-6B MODEX: INSPECT. DATE: --
SQUADRON: NADEP JACKSONVILLE INACTIVE: --
LAST UPDATE: 02-06-04 COMMENTS for AIRFRAME
S.D.L.M. DUE DATE: -- CUSTODY DATE: 02-06-04

SEAT 1 DESIG.: PILOT SEAT 3 DESIG.: ECMO-2
SEAT 1 PART: MK GRUEA7 SEAT 3 PART: MK GRUEA7
SEAT 1 SERIAL: 1269 SEAT 3 SERIAL: 1268
 COMMENTS for SEAT 1 COMMENTS for SEAT 3

SEAT 2 DESIG.: ECMO-1 SEAT 4 DESIG.: ECMO-3
SEAT 2 PART: MK GRUEA7 SEAT 4 PART: MK GRUEA7
SEAT 2 SERIAL: 1274 SEAT 4 SERIAL: 1267
 COMMENTS for SEAT 2 COMMENTS for SEAT 4

Start Login Fra... C:\Trace... Microsoft... Install... 11:26 AM



Audio:

SDLM is only available for use by Depot activities to strip assets from a Bu/Ser. Find the Bu/Ser you wish to strip of its assets and then click the SDLM button.

Developer Notes

12/30/2002



DODICs.ppt

88

Strip the Bu/Ser Logbook for S.D.L.M (Screen 2 of 5)

View | Lots

- Only depot-level activities are authorized to strip the assets from a Bu/Ser. All other activities will receive a warning stating they do not have sufficient rights.
- Depot-level activities will be prompted to confirm they wish to strip assets and move them to a ready service locker.



Audio:

Non-depot level activities will receive a warning indicating they do not have sufficient privileges to strip the assets and will not be allowed to strip assets.


Depot-level activities will be prompted to confirm they wish to strip assets and move them to a ready service locker.

Strip the Bu/Ser Logbook for S.D.L.M (Screen 3 of 5)

View | Lots

- A warning displays indicating you have chosen scheduled depot-level maintenance.
- Click OK to continue or Cancel to abort.

The screenshot shows a web-based application window titled "VFS - CAD/PAD: Bu/Sers Screen". The interface includes a menu bar with "Find", "Edit", "Add", "Cancel", "Delete", "Save", and "Help". A left sidebar contains buttons for "CONFIG", "CUSTODY", "FREEZE!", "S.D.L.M.", "REDESIG", and "RETURN". The main area contains various input fields for aircraft information, including BU/SER (161118), AIRCRAFT (EA-6B), MODEX, SQUADRON (NADEP JACKSONVILLE), LAST UPDATE (02-06-04), and S.D.L.M. DUE DATE. A warning dialog box is open over the SEAT 1 SERIAL field (126), displaying the text "SCHEDULED DEPOT LEVEL MAINTENANCE" and buttons for "OK" and "Cancel". Other fields include SEAT 1 PART (MH), SEAT 1 DESIG. (PIL), SEAT 2 DESIG. (ECMO-1), SEAT 2 PART (MK GRUEA7), SEAT 2 SERIAL (1274), SEAT 3 DESIG. (ECMO-2), SEAT 3 PART (MK GRUEA7), SEAT 3 SERIAL (1268), SEAT 4 DESIG. (ECMO-3), and SEAT 4 PART (MK GRUEA7). The Windows taskbar at the bottom shows the Start button, system tray, and taskbar icons.



Audio:

The system warns the user that Scheduled Depot Level Maintenance was chosen. Click OK to continue.

Developer Notes

12/30/2002



DODICs.ppt

90

Strip the Bu/Ser Logbook for S.D.L.M (Screen 4 of 5)

View | Lots

- A second warning will display stating that a SDLM process will strip the Bu/Ser of its installed assets.
- Click Yes to continue or No to stop.



Audio:

Another warning displays stating that a SDLM process will strip the Bu/Ser of all its installed assets. Click Yes to continue the process.

Developer Notes

12/30/2002



DODICs.ppt

91

Strip the Bu/Ser Logbook for S.D.L.M (Screen 5 of 5)

View | Lots

- You will be prompted whether or not to print a LogBook. Click Yes to print the LogBook or No to continue stripping assets without printing the LogBook.



Audio:

The system will prompt you to print a log book. Click Yes if you wish to print the log book; otherwise click No.

Developer Notes

12/30/2002

DODICs.ppt

92

Redesignate Aircraft Platform (Screen 1 of 6)

View | Lots

- To redesignate an aircraft platform, you must contact Indian Head personnel.

Commercial: (301)744-2233

DSN: 354-2233

Fax: (301)744-6699/4881

Email: cadpadtrace@ih.navy.mil



Audio:

Only approved Indian Head personnel have the ability to redesignate an aircraft platform.

Developer Notes

12/30/2002


DODICs.ppt

93

Accessing Squadron Information

View | Lots

- To access squadron information, click the SQUADRONS button from the VFS Trace Main Menu.
- The VFS – CAD/PAD Squadrons Screen will display.



Audio:

Click the Squadrons button from the Main Menu to access Squadron information.

Developer Notes

12/30/2002

DODICs.ppt

94

Squadron Menu Options

View | Lots

- To view the training, click the Next arrow for sequential order or click a step-by-step training topic from the menu at the top of the screen.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

ALT.POCs
RETURN


VFS - CAD/PAD Squadrons Screen

Find Edit Add Cancel Delete Save Help

SQUADRON: _____ ORG. CODE: _____
WING: _____ QUARTERLY: _____
TYCOM: _____ OOMA SQUADRON:

ADDRESSEE: _____ SERVICE: _____
DESIGNATION: _____ P.O.C. _____
STATION: _____ PHONE - Autovon _____
ADDRESS: _____ PHONE - Commercial () _____
CITY: _____ FACSIMILE - Fax _____
STATE: _____ ZIP: _____ E-MAIL ADDRESS: _____

Start Login Fra... C:\Trace... Microsoft... Install... 11:41 AM



Audio:

Training for the Squadrons section may be viewed sequentially by using the Next button at the bottom right of this window or section by section using the menu at the top of the screen.

Developer Notes

12/30/2002

DODICs.ppt

95

Adding a Squadron

View | Lots

- To add a squadron, you must contact Indian Head personnel.

Commercial: (301)744-2233

DSN: 354-2233

Fax: (301)744-6699/4881

Email: Cadpadtrace@ih.navy.mil



Audio:

To add a squadron, notify the CAD/PAD Trace office to ensure proper fleet representation.

Developer Notes

12/30/2002


DODICs.ppt

96

Finding a Squadron – Screen 1

View | Lots

- Click the Find button to display the FIND window.
- To search by squadron, select the check box next to SQUADRON and type a squadron in the FIND field.
- To search by organization code, click the check box next to ORG. CODE and type an organization code in the FIND field.
- Press Enter to display the search results.



Audio:

To locate a squadron's information, click the Find button. A squadron's information may be located by squadron name or organization code.

Developer Notes

12/30/2002

DODICs.ppt

97

Finding a Squadron – Screen 2

View | Lots

- A list of squadrons will display.
- Double-click a squadron to display its information.

SQUADRON	ORG.	SQUADRON NAME
VFA-106	AA7	NAVAL AIR STATION OCEANA STRKFITRON
VFA-113	PD4	ATTN AME SHOP STRKFITRON
VFA-116	PD5	NAS LEMOORE STRKFITRON ONE ONE
VFA-122	PE3	LOGS AND RECORDS OFFICE
VFA-125	PE4	SERVICE ENGINEER SQUADRON

Audio:

A table will display with the squadron that was searched for listed at the top. Double-click a squadron to display its data.

Developer Notes

12/30/2002

DODICs.ppt

98

Finding a Squadron – Screen 3

View | Lots

- The squadron information will display.

NOTE: Squadron locations are not available for user viewing.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

ALT.POCs
RETURN


VFS - CAD/PAD Squadrons Screen

Find Edit Add Cancel Delete Save Help

SQUADRON: NADEP JACKSONVILLE ORG. CODE: WC3
WING: UNASGN TO WING QUARTERLY: 01-11-30
TYCOM: CNASC OOMA SQUADRON:

ADDRESSSEE: [dropdown] SERVICE: NAVY
DESIGNATION: [input] CAD/PAD [dropdown] P.O.C. WANZALINE MCHENRY
STATION: [input] PHONE - Autovon 8-942-2104
ADDRESS: [input] PHONE - Commercial [input] [input] ~ [input]
CITY: [input] FACSIMILE - Fax [input]
STATE: [input] ZIP: [input] E-MAIL ADDRESS: MCHENRYWW@NAVAIR.NAVY.M

Start [icons] [Login Fra...] [C:\Trace...] [Microsoft...] [Installe...] [system tray] 11:47 AM



Audio:

The squadron information will display in the main screen area.

Developer Notes

12/30/2002

DODICs.ppt

99

Editing – Squadron Information (Screen 1 of 5)

View | Lots

- To edit squadron information, **find the squadron** and click the Edit button.

- Editable fields will highlight green.

NOTE: Squadron information may only be changed by personnel in the selected squadron.

The screenshot shows two instances of the 'VFS - CAD/PAD Squadrons Screen' application. The top instance has the 'Edit' button highlighted in green. The bottom instance shows the main form with several fields highlighted in green, indicating they are editable. The form includes fields for SQUADRON, WING, TYCOM, ADDRESSSEE, DESIGNATION, STATION, ADDRESS, CITY, STATE, ZIP, SERVICE, PHONE, FACSIMILE, and E-MAIL ADDRESS. The P.O.C. field is also highlighted in green.

SQUADRON:	NADEP JACKSONVILLE	ORG. CODE:	WC3
WING:	UNASGN TO WING	QUARTERLY:	01-11-30
TYCOM:	CNASC	OOMA SQUADRON:	<input type="checkbox"/>
ADDRESSSEE:		SERVICE:	NAVY
DESIGNATION:		CAD/PAD	P.O.C. WANZALINE MCHENRY
STATION:		PHONE - Autovon	S- 942 ~ 2104
ADDRESS:		PHONE - Commercial	() ~
CITY:		FACSIMILE - Fax	
STATE:		E-MAIL ADDRESS:	MCHENRYWW@NAVAIR.NAVY.M
ZIP:			

Audio:

To edit squadron information, use the Find option to locate a squadron and then click Edit from the menu at the top of the screen. The background color for information that may be edited will highlight green. Only personnel located within the selected squadron or those who have squadron rights will have the authority to edit information.

Developer Notes

12/30/2002

DODICs.ppt

100

Editing – Squadron Information (Screen 2 of 5)

View | Lots

- A squadron may have different points of contact for CAD/PAD, Life Support, 1-877, and SLE.
- In the POC list, click a point of contact type to display the appropriate point of contact.
- Type the information for the selected point of contact in the green highlighted fields.

The screenshot shows a web-based application window titled "VFS - CAD/PAD Squadrons Screen". The window has a menu bar with "Find", "Edit", "Add", "Cancel", "Delete", "Save", and "Help". On the left, there is a logo for NAVSEA INDIAN HEAD Surface Warfare Center Division CAD/PAD, with buttons for "ALT.POCs" and "RETURN". The main form contains the following fields:

SQUADRON:	NADEP JACKSONVILLE	ORG. CODE:	WC3
WING:	UNASGN TO WING	QUARTERLY:	01-11-30
TYCOM:	CNASC	OOMA SQUADRON:	<input type="checkbox"/>
ADDRESSEE:	[Dropdown]	SERVICE:	NAVY
DESIGNATION:	[Text]	CAD/PAD	P.O.C. WANZALINE MCHENRY
STATION:	[Text]	CAD/PAD	8- 942 ~ 2104
ADDRESS:	[Text]	LIFE SUPPORT	1-877 () ~
CITY:	[Text]	S.L.E.	[Text]
STATE:	[Text]	ZIP:	[Text]
		E-MAIL ADDRESS:	MCHENRYWWW@NAVAIR.NAVY.M

The bottom of the window shows a Windows taskbar with the Start button, several application icons, and a system tray with the time 11:51 AM.



Audio:

To update a squadron's list of alternate points of contact, click the type of alternate point of contact to edit or add from the POC list. Type new or updated contact information for the POC.

Developer Notes

12/30/2002

DODICs.ppt

101

Editing –Squadron Information (Screen 3 of 5)


View | Lots

- Click the Save button to store changed information in the system or click cancel.

The screenshot shows a web-based application window titled "VFS - CAD/PAD Squadrons Screen". The window has a menu bar with "Find", "Edit", "Add", "Cancel", "Delete", "Save", and "Help" buttons. Below the menu bar is a logo for NAVSEA (Naval Air Warfare Center Division) and two buttons: "ALT.POCs" and "RETURN". The main form contains the following fields:

SQUADRON:	NADEP JACKSONVILLE	ORG. CODE:	WC3
WING:	UNASGN TO WING	QUARTERLY:	01-11-30
TYCOM:	CNASC	OOMA SQUADRON:	<input type="checkbox"/>
ADDRESSEE:	<input type="text"/>	SERVICE:	NAVY
DESIGNATION:	<input type="text"/>	LIFE SUPPO	P.O.C. JOHN SMITH
STATION:	<input type="text"/>	PHONE - Autovon	8-744 ~ 2253
ADDRESS:	<input type="text"/>	PHONE - Commercial	(301) 744 ~ 2253
CITY:	<input type="text"/>	FACSIMILE - Fax	<input type="text"/>
STATE:	<input type="text"/>	ZIP:	<input type="text"/>
		E-MAIL ADDRESS:	<input type="text"/>

The Windows taskbar at the bottom shows the Start button, several application icons, and the system tray with the time 11:54 AM.



Audio:

When editing is complete, click the Save button to store changed information or click Cancel.

Developer Notes

12/30/2002

DODICs.ppt

102

Deleting a Squadron

View | Lots

- To delete a squadron, you must contact Indian Head personnel.

Commercial: (301)744-2233

DSN: 354-2233

Fax: (301)744-6699/4881

Email: Cadpadtrace@ih.navy.mil



Audio:

Only approved Indian Head personnel can delete a squadron from the system.

Developer Notes

12/30/2002

DODICs.ppt

103

Alt. POCs - Viewing

View | Lots

- To view alternate point of contact information, [find the squadron](#) and click the ALT. POCs button on the upper left-hand side of the screen.
- A table will display at the bottom of the screen listing alternate points of contact.

NOTE: For training on how to edit the alternate point of contact list, go to the [Edit Alt. POC](#) section.

The screenshot shows a web application window titled "VFS - CAD/PAD Squadrons Screen". On the left is a sidebar with the NAVSEA logo and buttons for "ALT.POCs" and "RETURN". The main area contains a menu bar (Find, Edit, Add, Cancel, Delete, Save, Help) and a form with the following fields:

- SQUADRON: NADEP JACKSONVILLE
- WING: UNASGN TO WING
- TYCOM: CNASC
- ORG. CODE: WC3
- QUARTERLY: 01-11-30
- OOMA SQUADRON:
- ADDRESSEE: [Dropdown]
- SERVICE: NAVY
- DESIGNATION: [Text]
- P.O.C.: WANZALINE MCHENRY
- STATION: [Text]
- PHONE - Autovon: 8-942-2104
- ADDRESS: [Text]
- PHONE - Commercial: () ~

At the bottom, a table lists alternate points of contact:

SOURCE	CONTACT	AUTOVON	TELEPHONE	FACSIMILE	E-MAIL
CADIPAD	WANZALINE MCHENRY	942 2104			MCHENRYWW@NAVAIR.NAVY.
LIFE SUPPC	JOHN SMITH	744 2253	301 744 2253		

Audio:

To view a squadron's list of alternate points of contact, use the Find option to locate a squadron. Next, click the Alt. POCs button to view a table on the bottom of the screen. The table will contain a list of all alternate points of contact currently associated with the selected squadron.

Developer Notes

12/30/2002


DODICs.ppt

104

Accessing Report Information

View | Lots

- Click the REPORTS button from the Main Menu to access the Reports section.




Audio:

Click the REPORTS button from the Main Menu of the VFS Trace Application to view various reports. This feature does not provide edit capabilities.

Select Report for Viewing

View | Lots

- The VFS - CAD/PAD Report Generator screen displays.
- Click a report from the drop-down list box to view its information.



Audio:

On initial entry of the REPORT section, you must first select a report for viewing. To view training for a specific report, use the drop-down list box at the bottom of this window.

01 DODIC Report

View | Lots

- Click the DODIC REPORT from the SELECT REPORT list.
- The report includes options for all records, custodian, or Bu/Ser.
- The report displays specific installed DODICs by lot number and quantity of each.
- The DODIC Report includes the following fields: Custodian, Squadron, Type A/C, Modex, BuSer, Lot Number, and Total.

Installed, ver 1.0.0.2 . Connected from: http://cadpadvfs

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

RETURN

VFS - CAD/PAD Report Generator

SELECT REPORT:
01 DODIC REPORT

Cancel

OPTIONS:

ALL RECORDS
 CUSTODIAN
 BUSER



Audio:

Click the DODIC Report from the SELECT REPORT list. The DODIC report displays specific installed DODICs by lot number and quantity of each.

Developer Notes

12/30/2002

DODICs.ppt

107

01 DODIC Report – All Records Option

View | Lots

- Click the DODIC REPORT in the SELECT REPORT list and the ALL RECORDS option, and then press Enter to display the report.
- Type a DODIC in the DODIC box and then press Enter to display the report based on a specific DODIC.

ected from: <http://cadpadvfs>

VFS - CAD/PAD Report Generator

SELECT REPORT:
01 DODIC REPORT

Cancel

OPTIONS:

ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
[]

Press ENTER after selections



Audio:

Click the DODIC report in the SELECT REPORT list and the ALL RECORDS option. Press Enter to display all DODIC records. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

01 DODIC Report – Custodian Option

View | Lots

- Click the DODIC REPORT in the SELECT REPORT list and the CUSTODIAN option.
- Select a custodian from the Custodian list and then press Enter to display the report based on the selected custodian.
- To view a specific DODIC for that selected custodian, type a DODIC in the DODIC box.

ected from: <http://cadpadvfs>

VFS - CAD/PAD Report Generator

SELECT REPORT:
01 DODIC REPORT

Cancel

OPTIONS:

ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
[]

Custodian:
[]

Press ENTER after selections



Audio:

Click the DODIC REPORT in the SELECT REPORT list and the CUSTODIAN option. Click a custodian in the Custodian list and then press Enter. The DODIC report displays DODICs for the selected custodian. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

01 DODIC Report – Bu/Ser Option

View | Lots

- Click the DODIC REPORT in the SELECT REPORT list and the BUSER option.
- Type a Bu/Ser in the Buser box to restrict the report to a specific Bu/Ser and then press Enter to display the report.
- To view a specific DODIC for that Bu/Ser, type a DODIC in the DODIC box.

Connected from: <http://cadpadvfs>

VFS - CAD/PAD Report Generator

SELECT REPORT:
01 DODIC REPORT

Cancel

OPTIONS:

ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
[]

Buser:
[]

Press ENTER after selections




Audio:

Click the DODIC REPORT in the SELECT REPORT list and the BUSER option. Type a Bu/Ser in the Buser box and then press Enter. The DODIC report displays DODICs assigned to that Bu/Ser. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

02 Expired Parts Forecast Report

View | Lots

- Click the EXPIRED PARTS FORECAST report from the SELECT REPORT list.
- The report lists installed assets expiring within a specified time period and has options for detail or summary information.
- The EXPIRED PARTS FORECAST report includes the following fields: Custodian, Type A/C, Modex, BuSer, Seat/Part Number, DODIC, Part Number, Nomenclature, Lot Number, Serial Number, Expire Date, and Revise Date.



Audio:

Click the EXPIRED PARTS FORECAST report from the SELECT REPORT list to display installed assets that are due to expire within a specified time period.

Developer Notes

12/30/2002

DODICs.ppt

111

02 Expired Parts Forecast Report – Detail Option

View | Lots

- Click the EXPIRED PARTS FORECAST report from the SELECT REPORT list and the DETAIL option.
- Type the begin and end dates to set the range of the report and then press Enter to display the report.

Connected from: <http://cadpadvfs>

VFS - CAD/PAD Report Generator

SELECT REPORT:

02 EXPIRED PARTS FORECAST

Cancel

OPTIONS:

DETAIL

SUMMARY

Begin Date: 02/08/15

End Date: 02/11/15



Audio:

Click the EXPIRED PARTS FORECAST report from the SELECT REPORT list. In the OPTIONS section, click DETAIL. Type the begin and end dates to display installed assets due to expire within the specified timeframe.

Developer Notes

12/30/2002

DODICs.ppt

112

02 Expired Parts Forecast Report – Summary Option

View | Lots

- Click the EXPIRED PARTS FORECAST report from the SELECT REPORT list and the SUMMARY option.
- Type the begin and end dates to set the range of the report, and then press Enter to display the report.

Connected from: <http://cadpadvfs>

VFS - CAD/PAD Report Generator

SELECT REPORT:
02 EXPIRED PARTS FORECAST

Cancel

OPTIONS:

DETAIL
 SUMMARY

Begin Date: 02/08/15
End Date: 02/11/15



Audio:

Click the EXPIRED PARTS FORECAST report from the SELECT REPORT list. In the OPTIONS section, choose summary and type the begin date and end date. The EXPIRED PARTS FORECAST report displays installed assets that are due to expire within the timeframe you specified.

Developer Notes

12/30/2002

DODICs.ppt

113

02 Expired Parts Forecast Report – Summary Option – Extended Options

View | Lots

- Click the EXPIRED PARTS FORECAST report from the SELECT REPORT list and the SUMMARY option.
- Type the begin and end dates to set the range of the report.
- The report includes options for all records, custodian, and Bu/Ser.
- The EXPIRED PARTS FORECAST report displays installed assets that are due to expire based on your chosen options.

Connected from: http://cadpadvfs

VFS - CAD/PAD Report Generator

SELECT REPORT:
02 EXPIRED PARTS FORECAST

Cancel

OPTIONS:

DETAIL
 SUMMARY

Begin Date: 02/08/15
End Date: 02/11/15

ALL RECORDS
 CUSTODIAN
 BUSER



Audio:

Click the EXPIRED PARTS FORECAST report from the SELECT REPORT list. In the OPTIONS section, choose SUMMARY and type the begin and end dates. The Expired Parts Forecast report displays installed assets that are due to expire based on your chosen options.

Developer Notes

12/30/2002

DODICs.ppt

114

02 Expired Parts Forecast Report – Summary Option – All Records Option

View | Lots

- Click the EXPIRED PARTS FORECAST report in the SELECT REPORT list, the SUMMARY option, and the ALL RECORDS option.
- Type the begin and end dates to set the range of the report and then press Enter to display the report.
- Type a DODIC in the DODIC box and then press Enter to display the report based on a specific DODIC.

Installed, ver 1.0.0.2, Connected from: http://cadpadvls

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD Report Generator

SELECT REPORT:
02 EXPIRED PARTS FORECAST

RETURN Cancel

OPTIONS:
 DETAIL
 SUMMARY

Begin Date: 02/08/15
End Date: 02/11/15

ALL RECORDS
 CUSTODIAN
 BUUSER

DODIC:
[]

Press ENTER after selections

Audio:

Click the EXPIRED PARTS FORECAST report in the SELECT REPORT list, the SUMMARY option, and the ALL RECORDS option. Type the begin and end dates to set the range of the report. Press Enter to display the report. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

Developer Notes

12/30/2002

DODICs.ppt

115

02 Expired Parts Forecast Report – Summary Option – Custodian Option

View | Lots

- Click the EXPIRED PARTS FORECAST report in the SELECT REPORT list, the SUMMARY option, and the CUSTODIAN option.
- Type the begin and end dates to set the range of the report.
- Select a custodian from the Custodian list and then press Enter to display the report.
- Type a DODIC in the DODIC box and press Enter to display the report based on a specific DODIC.

Installed, ver 1.0.0.2, Connected from: http://cadpad/vfs

NAVSEA
INFORMAL HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD Report Generator

SELECT REPORT:
02 EXPIRED PARTS FORECAST

RETURN Cancel


OPTIONS:

DETAIL
 SUMMARY

Begin Date: 02/08/15
End Date: 02/11/15

ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
Custodian:
Press ENTER after selections



Audio:

Click the EXPIRED PARTS FORECAST report in the SELECT REPORT list, the SUMMARY option, and the CUSTODIAN option. Type the begin and end dates to set the range of the report. Select a custodian from the Custodian list and then press Enter. The report lists installed assets expiring within the specific time period for the selected custodian. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

02 Expired Parts Forecast Report – Summary Option – Buser Option

View | Lots

- Click the EXPIRED PARTS FORECAST report in the SELECT REPORT list, the SUMMARY option, and the BUSER option.
- Type the begin and end dates to set the range of the report.
- Type a Bu/Ser in the Buser box to restrict the report to a specific Bu/Ser and then press Enter to display the report.
- Type a DODIC in the DODIC box and then press Enter to display the report based on the specific DODIC.

Installed, ver 1.0.0.2. Connected from: http://cadpadvfs

NAVSEA
INMAN HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD Report Generator

SELECT REPORT:
02 EXPIRED PARTS FORECAST

RETURN Cancel

OPTIONS:

DETAIL
 SUMMARY

Begin Date: 02/08/15
End Date: 02/11/15

ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
Buser:
Press ENTER after selections

Audio:

Click the EXPIRED PARTS FORECAST in the SELECT REPORT list, the SUMMARY option, and the BUSER option. Type a Bu/Ser in the Buser box and press Enter to display the report. The report lists installed assets, expiring within the specific time period you entered, that belong to the selected Bu/Ser. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

Developer Notes

12/30/2002


DODICs.ppt

117

03 Part Number Report

View | Lots

- Click the PART NUMBER REPORT in the SELECT REPORT list to display installed assets based on specific part numbers.
- The report has assembly and service life options.
- The Part Number Report includes the following fields: Custodian, Activity, A/C, Modex, Bu/Ser, Seat Part Number, DODIC, Lot Number, Serial Number, Expire Date, Extension Date, and Total.



Audio:

Click the PART NUMBER REPORT in the SELECT REPORT list to display installed assets based on specific part numbers.

Developer Notes

12/30/2002

DODICs.ppt

118

03 Part Number Report – Assembly

View | Lots

- Click the PART NUMBER REPORT in the SELECT REPORT list and the ASSEMBLY option.
- The report includes options for all records, custodian, and Bu/Ser.

Connected from: <http://cadpadvfs>

VFS - CAD/PAD Report Generator

SELECT REPORT:
03 PART NUMBER REPORT

Cancel

OPTIONS:

ASSEMBLY
 SERVICE LIFE

ALL RECORDS
 CUSTODIAN
 BUSER




Audio:

Click the PART NUMBER REPORT in the SELECT REPORT list and choose ASSEMBLY under the OPTIONS section. The report has options for all all records, custodian, and Bu/Ser.

03 Part Number Report – Assembly – All Records Option

View | Lots

- Click the PART NUMBER REPORT in the SELECT REPORT list, the ASSEMBLY option, and the ALL RECORDS option, then press Enter to display the report.
- Type a DODIC in the DODIC box and then press Enter to display the report based on a specific DODIC.



Audio:

Click the PART NUMBER REPORT in the SELECT REPORT list, the ASSEMBLY option, and the ALL RECORDS option. Press Enter to display the report. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

03 Part Number Report – Assembly – Custodian Option

View | Lots

- Click the PART NUMBER REPORT in the SELECT REPORT list box, the ASSEMBLY option, and the CUSTODIAN option.
- Select a custodian from the Custodian list and press Enter to display the report.
- Type a DODIC in the DODIC box and press Enter to display the report based on a specific DODIC.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

NAVSEA
INCH/HEAD
Surface Warfare Center Division
CAD/PAD

RETURN

VFS - CAD/PAD Report Generator

SELECT REPORT:
03 PART NUMBER REPORT

Cancel

OPTIONS:

ASSEMBLY
 SERVICE LIFE

ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
[Text Input]

Custodian:
[Dropdown]

Press ENTER after selections



Audio:

Click the PART NUMBER REPORT in the SELECT REPORT list, the ASSEMBLY option, and the CUSTODIAN option. Select a custodian from the Custodian list and then press Enter. The report displays installed assets, based on specific part numbers and assembly, belonging to the selected custodian. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

Developer Notes

12/30/2002

DODICs.ppt

121

03 Part Number Report – Assembly – Buser Option

View | Lots

- Click the PART NUMBER REPORT in the SELECT REPORT list, the ASSEMBLY option, and the BUSER option.
- Type a Bu/Ser in the Buser box to restrict the report to a specific Bu/Ser and then press Enter to display the report.
- Type a DODIC in the DODIC box and press Enter to display the report for the specific DODIC.

Installed, ver 1.0.0.2 . Connected from: http://cadpad/vfs

NAVSEA
UNCLASSIFIED
Surface Warfare Center Division
CAD/PAD
RETURN

VFS - CAD/PAD Report Generator

SELECT REPORT:
03 PART NUMBER REPORT
Cancel

OPTIONS:
 ASSEMBLY
 SERVICE LIFE
 ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
Buser:
Press ENTER after selections



Audio:

Click the PART NUMBER REPORT in the SELECT REPORT list, the ASSEMBLY option, and the BUSER option. Type a Bu/Ser in the Buser box and then press Enter to display the report. The report displays installed assets, based on specific part numbers and assembly, belonging to the selected Bu/Ser. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

Developer Notes

12/30/2002

DODICs.ppt

122

03 Part Number Report – Service Life

View | Lots

- Click the PART NUMBER REPORT in the SELECT REPORT list and the SERVICE LIFE option.
- The report includes options for all records, custodian, or Bu/Ser.

Connected from: <http://cadpadvfs>

VFS - CAD/PAD Report Generator

SELECT REPORT:
03 PART NUMBER REPORT

Cancel

OPTIONS:

ASSEMBLY
 SERVICE LIFE

ALL RECORDS
 CUSTODIAN
 BUSER




Audio:

Click the PART NUMBER report in the SELECT REPORT list and the SERVICE LIFE option. The PART NUMBER report displays based on your chosen options.

03 Part Number Report – Service Life – All Records Option

View | Lots

- Click the PART NUMBER REPORT in the SELECT REPORT list, the SERVICE LIFE option, and the ALL RECORDS option, then press Enter to display the report.
- Type a DODIC in the DODIC box and press Enter to display the report based on the specific DODIC.




Audio:

Click the PART NUMBER REPORT in the SELECT REPORT list, the SERVICE LIFE option, and the ALL RECORDS option. Press Enter to display the report. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

03 Part Number Report – Service Life – Custodian Option

View | Lots

- Click the PART NUMBER REPORT in the SELECT REPORT list, the SERVICE LIFE option, and the CUSTODIAN option.
- Select a custodian from the Custodian list and then press Enter to display the report based on the selected custodian.
- Type a DODIC in the DODIC box and press Enter to display the report based on the specific DODIC.



Audio:

Click the PART NUMBER REPORT in the SELECT REPORT list, the SERVICE LIFE option, and the CUSTODIAN option. Select a custodian from the Custodian list and then press Enter. The report displays installed assets, based on specific part numbers and service life, belonging to the selected custodian. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

03 Part Number Report – Service Life – Buser Option

View | Lots

- Click the PART NUMBER REPORT in the SELECT REPORT list, the SERVICE LIFE option, and the BUSER option.
- Type a Bu/Ser in the Buser box to restrict the report to a specific Bu/Ser and then press Enter to display the report.
- Type a DODIC in the DODIC box and press Enter to display the report based on the specific DODIC.

Installed, ver 1.0.0.2 . Connected from: http://cadpadvis

NAVSEA
NICKAM HEAD
Surface Warfare Center Division
CAD/PAD
RETURN

VFS - CAD/PAD Report Generator

SELECT REPORT:
03 PART NUMBER REPORT
Cancel

OPTIONS:

ASSEMBLY
 SERVICE LIFE

ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
Buser:
Press ENTER after selections

Audio:

Click the PART NUMBER REPORT in the SELECT REPORT list, the SERVICE LIFE option, and the BUSER option. Type a Bu/Ser in the Buser box and then press Enter to display the report. The report displays installed assets, based on specific part numbers and service life, belonging to the selected Bu/Ser. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

Developer Notes

12/30/2002

DODICs.ppt

126

04 Custodian Report

View | Lots

- Click the CUSTODIAN REPORT in the SELECT REPORT list.
- In the OPTIONS section, choose a specific custodian using the Custodian list and then press Enter to display the report.
- The CUSTODIAN Report displays, providing a listing of the Type Aircraft, Bu/Ser, Seat Part Number, and Seat Serial Number based on the specific custodian code you selected.

connected from: http://cadpadvfs

VFS - CAD/PAD Report Generator

SELECT REPORT:
04 CUSTODIAN REPORT

Cancel

OPTIONS:

Custodian:
[]

Press ENTER after selections



Audio:

Click the CUSTODIAN REPORT from the SELECT REPORT list. In the OPTIONS section, choose a specific custodian and then press Enter. The CUSTODIAN REPORT displays.

Developer Notes

12/30/2002

DODICs.ppt

127

05 Custodian Maintenance Due

View | Lots

- Click the CUSTODIAN MAINTENANCE DUE report in the SELECT REPORT list.
- In the OPTIONS section, choose a specific custodian using the Custodian list and then press Enter to display the report.
- The CUSTODIAN MAINTENANCE DUE report includes the following fields: Type Aircraft, Bu/Ser, Seat Part Number, Seat Serial Number, Maintenance Cycle, Due Date, Custody Date, and Last Update.

Installed, ver 1.0.0.2 - Connected from: http://cadpadvts

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD Report Generator

SELECT REPORT:
05 CUSTODIAN MAINTENANCE DUE

RETURN Cancel

OPTIONS:
Custodian:
Press ENTER after selections



Audio:

Click the CUSTODIAN MAINTENANCE DUE report from the SELECT REPORT list and choose a specific custodian in the OPTIONS section. The report displays providing a list of each BuSer and when the maintenance cycle is scheduled.

Developer Notes

12/30/2002



DODICs.ppt

128

06 Extension Report

View | Lots

- Click the EXTENSION REPORT in the SELECT REPORT list.
- The report includes options for all records, custodian, or Bu/Ser.
- The EXTENSION report includes the following fields: Custodian, Type A/C, Bu/Ser, Seat/Part Number, DODIC, Nomenclature, Location, Lot Number, Serial Number, Expire Date, Revised Date, and Extension.



Audio:

Click the EXTENSION REPORT in the SELECT REPORT list. The EXTENSION Report displays data on when installed assets expire.

Developer Notes

12/30/2002


DODICs.ppt

129

06 Extension Report – All Records Option

View | Lots

- Click the EXTENSION REPORT in the SELECT REPORT list and the ALL RECORDS option, then press Enter to display the report.
- Type a DODIC in the DODIC box and press Enter to display the report based on the specific DODIC.



Audio:

Click the EXTENSION REPORT in the SELECT REPORT list and the ALL RECORDS option. Press Enter to display the report. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

Developer Notes

12/30/2002

DODICs.ppt

130

06 Extension Report – Custodian Option

View | Lots

- Click the EXTENSION REPORT in the SELECT REPORT list and the CUSTODIAN option.
- Select a custodian from the Custodian list and then press Enter to display the report based on the selected custodian.
- Type a DODIC in the DODIC box and press Enter to display the report based on the specific DODIC.

Installed, ver 1.0.0.2 . Connected from: http://cadpad/vfs

NAVSEA
INMAN HEAD
Surface Warfare Center Division
CAD/PAD
RETURN

VFS - CAD/PAD Report Generator

SELECT REPORT:
06 EXTENSION REPORT
Cancel

OPTIONS:
 ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
Custodian:
Press ENTER after selections

Audio:

Click the EXTENSION REPORT in the SELECT REPORT list and the CUSTODIAN option. Select a custodian from the Custodian list and then press Enter. The report displays data on when installed assets belonging to the selected custodian expire. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

06 Extension Report – Buser Option

View | Lots

- Click the EXTENSION REPORT in the SELECT REPORT list, and the BUSER option.
- Type a Bu/Ser in the Buser box to restrict the report to a specific Bu/Ser and then press Enter to display the report.
- Type a DODIC in the DODIC box and press Enter to display the report based on the specific DODIC.

Installed, ver 1.0.0.2, Connected from: http://cadpadvts

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD


VFS - CAD/PAD Report Generator

SELECT REPORT:
06 EXTENSION REPORT

RETURN Cancel

OPTIONS:
 ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
Buser:
Press ENTER after selections




Audio:

Click the EXTENSION REPORT in the SELECT REPORT list and the BUSER option. Type a Bu/Ser in the Buser box and then press Enter to display the report. The report displays data on when installed assets, belonging to the selected Bu/Ser, expire. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

07 Lot Number Report

View | Lots

- Click the LOT NUMBER REPORT in the SELECT REPORT list.
- The report includes options for all records, custodian, or Bu/Ser.
- The LOT NUMBER report includes the following fields: Custody, Type A/C, Modex, Bu/Ser, Seat/Part Number, DODIC, Lot Number, and Total.



Audio:

Click the LOT NUMBER report in the SELECT REPORT list. The LOT NUMBER report displays the quantity of lot numbers per DODIC for installed assets.

Developer Notes

12/30/2002


DODICs.ppt

133

07 Lot Number Report – All Records Option

View | Lots

- Click the LOT NUMBER REPORT in the SELECT REPORT list, and the ALL RECORDS option, then press Enter to display the report.
- Type a DODIC in the DODIC box and press Enter to display the report based on the specific DODIC.



Audio:

Click the LOT NUMBER REPORT in the SELECT REPORT list and the ALL RECORDS option. Press Enter to display the report. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

Developer Notes

12/30/2002

DODICs.ppt

134

07 Lot Number Report – Custodian Option

View | Lots

- Click the LOT NUMBER REPORT in the SELECT REPORT list and the CUSTODIAN option.
- Select a custodian from the Custodian list and then press Enter to display the report based on the selected custodian.
- Type a DODIC in the DODIC box and press Enter to display the report based on the specific DODIC.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

RETURN

SELECT REPORT:
07 LOT NUMBER REPORT

Cancel

OPTIONS:

ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
[]

Custodian:
[]

Press ENTER after selections



Audio:

Click the LOT NUMBER REPORT in the SELECT REPORT list and the CUSTODIAN option. Select a custodian from the Custodian list and then press Enter. The report displays the quantity of lot numbers per DODIC for installed assets belonging to the selected custodian. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

Developer Notes

12/30/2002

DODICs.ppt

135

07 Lot Number Report – Buser Option

View | Lots

- Click the LOT NUMBER REPORT in the SELECT REPORT list and the BUSER option.
- Type a Bu/Ser in the Buser box to restrict the report to a specific Bu/Ser and then press Enter to display the report.
- Type a DODIC in the DODIC box and press Enter to display the report based on the specific DODIC.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD Report Generator

SELECT REPORT:
07 LOT NUMBER REPORT

RETURN Cancel

OPTIONS:
 ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
[]

Buser:
[]

Press ENTER after selections




Audio:

Click the LOT NUMBER REPORT in the SELECT REPORT list and the BUSER option. Type a Bu/Ser in the Buser box and then press Enter to display the report. The report displays the quantity of lot numbers per DODIC for installed assets belonging to the selected Bu/Ser. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

08 Seat Inspection Cycle Forecast Report

View | Lots

- Click the SEAT INSPECTION CYCLE FORECAST REPORT in the SELECT REPORT list.
- The report includes options for all records, custodian, or Bu/Ser.
- The SEAT INSPECTION CYCLE FORECAST Report includes the following fields: Custody, Type A/C, Modex, Bu/Ser, Seat/Part Number, DODIC, Nomenclature, Location, Lot Number, Serial Number, Expire Date, Inspection Cycle, Due Date, and Extension Date.



Audio:

Click the SEAT INSPECTION CYCLE FORECAST REPORT in the SELECT REPORT list. The report displays assets due to expire based upon the next scheduled maintenance cycle.

Developer Notes

12/30/2002


DODICs.ppt

137

08 Seat Inspection Cycle Forecast Report – All Records Option

View | Lots

- Click the SEAT INSPECTION CYCLE FORECAST REPORT in the SELECT REPORT list, and the ALL RECORDS option, then press Enter to display the report.
- Type a DODIC in the DODIC box and press Enter to display the report based on the specific DODIC.



Audio:

Click the SEAT INSPECTION CYCLE FORECAST REPORT in the SELECT REPORT list and the ALL RECORDS option. Press Enter to display the report. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

08 Seat Inspection Cycle Forecast Report – Custodian Report

View | Lots

- Click the SEAT INSPECTION CYCLE FORECAST REPORT in the SELECT REPORT list and the CUSTODIAN option.
- Select a custodian from the Custodian list and then press Enter to display the report based on the selected custodian.
- Type a DODIC in the DODIC box and press Enter to display the report based on the specific DODIC.

Installed, ver 1.0.0.2 . Connected from: http://cadpadvls

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD
RETURN

VFS - CAD/PAD Report Generator

SELECT REPORT:
08 SEAT INSPECTION CYCLE FORECAST REPORT
Cancel

OPTIONS:
 ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
[Text Box]

Custodian:
[Dropdown Menu]

Press ENTER after selections



Audio:

Click the SEAT INSPECTION CYCLE FORECAST REPORT in the SELECT REPORT list and the CUSTODIAN option. Select a custodian from the Custodian list and then press Enter. The report displays assets due to expire based upon the next scheduled maintenance cycle belonging to the selected custodian. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

Developer Notes

12/30/2002

DODICs.ppt

139

08 Seat Inspection Cycle Forecast Report – Buser Option

View | Lots

- Click the SEAT INSPECTION CYCLE FORECAST REPORT in the SELECT REPORT list and the BUSER option.
- Type a Bu/Ser in the Buser box to restrict the report to a specific Bu/Ser and then press Enter to display the report.
- Type a DODIC in the DODIC box and press Enter to display the report based on the specific DODIC.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD
RETURN

VFS - CAD/PAD Report Generator

SELECT REPORT:
08 SEAT INSPECTION CYCLE FORECAST REPORT
Cancel

OPTIONS:
 ALL RECORDS
 CUSTODIAN
 BUSER

DODIC:
Buser:
Press ENTER after selections



Audio:

Click the SEAT INSPECTION CYCLE FORECAST REPORT in the SELECT REPORT list and the BUSER option. Type a Bu/Ser in the Buser box and then press Enter to display the report. The report displays assets due to expire based upon the next scheduled maintenance cycle belonging to the selected Bu/Ser. Alternatively, you can enter a DODIC to restrict the report to the specific DODIC.

Developer Notes

12/30/2002


DODICs.ppt

140

09 DODIC Expiration Date

View | Lots

- Click the DODIC EXPIRATION DATE report in the SELECT REPORT list.
- In the OPTIONS section, choose a specific custodian using the Custodian list and then press Enter to display the report.
- The DODIC EXPIRATION DATE report includes the following fields: Custody, Activity, Aircraft, Modex, Bu/Ser, DODIC, Lot Number, Serial Number, Manufacturer Date, Open Date, Expire Date, and Extension Date.



Audio:

Click the DODIC EXPIRATION DATE report in the SELECT REPORT list. In the OPTIONS section, choose a specific custodian using the custodian list and then press Enter. The report displays, providing a list of all installed assets by expiration date.

Developer Notes

12/30/2002


DODICs.ppt

141

10 Set DODIC Expiration

View | Lots

- Click the SET DODIC EXPIRATION report in the SELECT REPORT list.
- In the OPTIONS section, choose a specific custodian using the Custodian list and then press Enter to display the report.
- The SET DODIC EXPIRATION report includes the following fields: Squadron, Custody, Aircraft Type, Modex, Bu/Ser, DODIC, Lot Number, Open Date, Expire Date, Extension Date, and Remarks (Denotes the controlling line for the explosive set).



Audio:

Click the SET DODIC EXPIRATION report in the SELECT REPORT list. In the OPTIONS section, choose a specific custodian using the custodian list and then press Enter. The report displays providing a list of all installed explosive sets.

Developer Notes

12/30/2002


DODICs.ppt

142

11 BUNOs Listing by Squadron

View | Lots

- Click the BUNOS LISTING BY SQUADRON report in the SELECT REPORT list and then press Enter to display the report.
- The BUNOS LISTING BY SQUADRON report includes the following fields: Squadron, Aircraft, Bu/Ser, Last Update, Custody Date, Inspection Cycle, and Next Inspection.



Audio:

Click the BUNOS LISTING BY SQUADRON report in the SELECT REPORT list and then press Enter to display the report. The report displays a listing of all aircraft for the entire VFS TRACE system.

Developer Notes

12/30/2002

DODICs.ppt

143

12 CADS to be Replaced in One Year

View | Lots

- Click the CADS TO BE REPLACED IN ONE YEAR report in the SELECT REPORT list.
- In the OPTIONS section, type a specific DODIC in the DODIC box, type a start date in the MM-YY box, and then press Enter to display the report.
- The CADS TO BE REPLACED IN ONE YEAR report includes the following fields: Squadron, BuSer, Prior, and Months.
- The Prior box contains the quantity expired prior to the requested start date and the Months box displays the twelve months listed beginning with the start date.

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD Report Generator

SELECT REPORT:
12 CADS TO BE REPLACED IN ONE YEAR

RETURN Cancel

OPTIONS:
DODIC
MM-YY
Press ENTER after selections



Audio:

Click the CADS TO BE REPLACED IN ONE YEAR report in the SELECT REPORT list. Type the appropriate information for the options of DODIC, and start date in MMY format. The report displays a listing of all CADS that expire within one year of the entered start date.

Developer Notes

12/30/2002



DODICs.ppt

144

13 Squadron Quarterly Report

View | Lots

- Click the SQUADRON QUARTERLY REPORT in the SELECT REPORT list and then press Enter to display the report.
- The SQUADRON QUARTERLY report includes the following fields: Squadron, Organization, Quarterly Date, TYCOM, and Wing.



Audio:

Click the SQUADRON QUARTERLY report in the SELECT REPORT list and then press Enter to display the report. The report provides a listing of all commands and last quarterly reporting into the system.

Developer Notes

12/30/2002

DODICs.ppt

145

14 Serial Numbers for Lot Number

View | Lots

- Click the SERIAL NUMBERS FOR LOT NUMBER report in the SELECT REPORT list.
- In the OPTIONS section, type a specific lot number in the LOT NUMBER box and specific DODIC in the DODIC box, then press Enter to display the report.
- The SERIAL NUMBERS FOR LOT NUMBER report includes the following fields: Serial No., BuSer, and Type A/C.

Installed, ver 1.0.0.2 . Connected from: http://cadpadvls

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

RETURN

Cancel

VFS - CAD/PAD Report Generator

SELECT REPORT:
14 SERIAL NUMBERS FOR LOT NUMBER

OPTIONS:

LOT NUMBER:
[Input Field]

DODIC:
[Input Field]

Press ENTER after selections



Audio:

Click the SERIAL NUMBERS FOR LOT NUMBER report in the SELECT REPORT list. In the OPTIONS section, type a specific lot number in the LOT NUMBER box, and a specific DODIC in the DODIC box, then press Enter to display the report. The report provides a listing of installed asset serial numbers based on the specific lot number and DODIC you entered.

Developer Notes

12/30/2002


DODICs.ppt

146

15 Transfer Custody Report

View | Lots

- Click the TRANSFER CUSTODY REPORT in the SELECT REPORT list and then press Enter to display the report.
- The TRANSFER CUSTODY report includes the following fields: Bu/Ser, Custodian, Physical Custody, Reporting Custody, Receiving Activity, Scheduled Transfer Date, and Transfer Authority.



Audio:

Click the TRANSFER CUSTODY report in the SELECT REPORT list and then press Enter to display the report. The report lists all aircraft currently in a transfer status.

Developer Notes

12/30/2002

DODICs.ppt

147

16 VFS Trace System by BuSer

View | Lots

- Click the VFS TRACE SYSTEM BY BUSER report in the SELECT REPORT list.
- In the OPTIONS section, type a specific DODIC in the DODIC box and then press Enter to display the report.
- The VFS TRACE SYSTEM BY BUSER report includes the following fields: Custody, Activity, Type A/C, BuSer, Lot Number, Serial Number, Manufacturer Date, Open Date, Installed Date, Expire Date, and Extension Date.

Installed, ver 1.0.0.2, Connected from: http://cadpad/vfs

NAVSEA
DODIC HEAD
Surface Warfare Center Division
CAD/PAD

VFS - CAD/PAD Report Generator

SELECT REPORT:
16 VFS TRACE SYSTEM BY BUSER

RETURN Cancel

OPTIONS:
DODIC
Press ENTER after selections



Audio:

Click the VFS TRACE SYSTEM BY BUSER report in the SELECT REPORT list and type the specific DODIC in the options section. Press Enter to display the report. The report provides a listing of the installed assets for the DODIC you entered.

Developer Notes

12/30/2002

DODICs.ppt

148

17 VFS Trace System by Lot Number

View | Lots

- Click the VFS TRACE SYSTEM BY LOT NUMBER report in the SELECT REPORT list.
- In the OPTIONS section, type a specific DODIC in the DODIC box and then press Enter to display the report.
- The VFS TRACE SYSTEM BY LOT NUMBER report includes the following fields:
Custody, Activity, Type A/C, BuSer, Lot Number, Serial Number, Manufacturer Date, Open Date, Installed Date, Expire Date, and Extension Date.

The screenshot shows a web-based application window titled "VFS - CAD/PAD Report Generator". The window has a blue header with the NAVSEA logo on the left and the title in the center. Below the header, there is a "SELECT REPORT:" section with a dropdown menu currently showing "17 VFS TRACE SYSTEM BY LOTNO". To the right of this is an "OPTIONS:" section with a text input field labeled "DODIC". Below the input field is a prompt that says "Press ENTER after selections". There are two buttons: "RETURN" on the left and "Cancel" in the middle. The window title bar indicates it is installed version 1.0.0.2 and is connected from the URL http://cadpadvfs.



Audio:

Click the VFS TRACE SYSTEM BY LOT NUMBER report in the SELECT REPORT list and type a specific DODIC in the options section. Press Enter to display the report. The report provides a listing of the installed assets for the DODIC you entered, in lot number order.

18 BUNOs Impacted by Lot Number

View | Lots

- Click the BUNOS IMPACTED BY LOT NUMBER report in the SELECT REPORT list.
- Type a specific lot number in the LOT NUMBER box and a specific DODIC in the DODIC box, utilizing the various wild cards, then press Enter to display the report.
- The BUNOS IMPACTED BY LOT NUMBER report includes the following fields: Bu/Ser and Aircraft.

Installed, ver 1.0.0.2 - Connected from: http://cadpadvfs

NAVSEA
INDIAN HEAD
Surface Warfare Center Division
CAD/PAD

RETURN

VFS - CAD/PAD Report Generator

SELECT REPORT:
18 BUNOS IMPACTED BY LOT NUMBER

Cancel

OPTIONS:

LOT NUMBER:
[]

DODIC:
[]

Press ENTER after selections

The * and ? characters represent wildcard entries.
i.e. ???89 - All lots produced in 1989.
HLX* - all lots beginning with HLX.
???92???????1?? All from 1992 ending w/ 1xx.

Audio:

Click the BUNOS IMPACTED BY LOT NUMBER report in the SELECT REPORT list, and enter a lot number and DODIC in the options section by using wild card options. Press Enter to display the report.

Developer Notes

12/30/2002

DODICs.ppt

150

Maintenance

View | Lots

- VFS Trace CAD/PAD maintenance may be performed by Indian Head personnel only.
- This option is used to:
 - track installed asset history
 - apply service life changes
 - perform lot validation




Audio:

The VFS Trace CAD/PAD maintenance section is not accessible to the Fleet. Only Indian Head personnel will have access to this option to track installed asset history, apply service life changes, and perform lot validation.

Help – Step 1

View | Lots



- Use the help screen to email the Trace CAD/PAD team for help.
- To create an email message, click the WRITE E-MAIL button.



Audio:

The VFS Trace CAD/PAD Help section provides a way for the user to send an email message to the Trace CAD/PAD team for support. Click the WRITE E-MAIL button located on the left-hand side of the screen to create an email message.

Developer Notes

12/30/2002

DODICs.ppt

152

Help – Step 2

View | Lots

Installed, ver 1.0.0.2, Connected from: http://cadpadvfs

VFS - CAD/PAD Help Screen



WRITE E-MAIL

SEND EMAIL

RETURN

TO: CADPADTRACE@IH.NAVY.MIL

FROM: MCHENRYWWW@NAVAIR.NAVY.MIL

SUBJECT: vfsCAD/PAD Help Question

How do I print a logbook?

- The TO, FROM, and SUBJECT text boxes fill automatically and cannot be modified.
- Type your message in the text box below the Subject.
- Click the SEND EMAIL button to send the message to the CAD/PAD Trace Team.



Audio:

The To, From, and Subject text boxes are automatically completed. Type your message in the text box below the Subject and click the SEND EMAIL button.

Developer Notes

12/30/2002

DODICs.ppt

153